


TransTig 2200 / 2500 Comfort
TransTig 3000 / 4000 Comfort
TransTig 5000 Comfort
MagicWave 2200 / 2500 Comfort
MagicWave 3000 / 4000 Comfort
MagicWave 5000 Comfort

Operating Instructions

EN

TIG Power source



42,0426,0063,EN 019-11122019

Contents

Safety rules	9
Explanation of safety notices	9
General	9
Proper use	9
Environmental conditions	10
Obligations of the operator	10
Obligations of personnel	10
Mains connection	10
Protecting yourself and others	11
Noise emission values	11
Danger from toxic gases and vapours	12
Danger from flying sparks	12
Risks from mains current and welding current	12
Meandering welding currents	13
EMC Device Classifications	14
EMC measures	14
EMF measures	15
Specific hazards	15
Requirement for the shielding gas	16
Danger from shielding gas cylinders	16
Danger from escaping shielding gas	16
Safety measures at the installation location and during transport	17
Safety measures in normal operation	17
Commissioning, maintenance and repair	18
Safety inspection	18
Disposal	18
Safety symbols	19
Data protection	19
Copyright	19
General information	21
General	23
Device concept	23
Functional principle	23
Application areas	23
System components	24
General	24
Overview	24
Control elements and connections	25
Description of the control panels	27
General	27
Safety	27
MagicWave Comfort control panel	27
TransTig Comfort control panel	29
Connections, switches and mechanical components	31
MagicWave2200 Comfort	31
MagicWave2500 / 3000 Comfort	32
MagicWave4000 / 5000 Comfort	33
TransTig2200 Comfort	34
TransTig2500 / 3000 Comfort	35
TransTig4000 / 5000 Comfort	36
Installation and commissioning	37
Minimum equipment needed for welding task	39
General	39
TIG AC welding	39

TIG DC welding.....	39
Automated TIG welding	39
MMA welding	39
Before installation and commissioning.....	40
Safety.....	40
Utilisation for intended purpose	40
Setup regulations	40
Mains connection	40
Start-up	42
Safety.....	42
Remarks on the cooling unit	42
General	42
Connecting the gas cylinder.....	42
Establishing a ground (earth) connection to the workpiece	43
Connecting the welding torch.....	43

Welding 45

TIG modes	47
Safety.....	47
Symbols and their explanations	47
2-step mode	48
Spot welding	49
4-step mode	50
Special 4-step mode: variant 1	51
Special 4-step mode: variant 2	51
Special 4-step mode: variant 3	52
Special 4-step mode: variant 4	52
Cap shaping and cap overloading	53
Cap-shaping.....	53
Cap overloading.....	53
TIG welding	54
Safety.....	54
Welding parameters: display and navigation	54
Welding parameters for TIG.....	54
Preparation	57
TIG welding.....	57
Igniting the arc	60
General	60
Igniting the arc using high frequency(HF ignition).....	60
Touchdown ignition	61
End of welding	62
Special functions and options	63
Arc break watchdog function.....	63
Ignition time-out function.....	63
TIG pulsing.....	63
Tacking function.....	64
TIG cold-wire welding	65
MMA welding	67
Safety.....	67
Welding parameters: display and navigation	67
Welding parameters for rod electrodes.....	68
Preparation	69
MMA welding	70
Hotstart function.....	71
Starting current <100% (SoftStart).....	72
Anti-stick function.....	72
Welding job	74
Safety.....	74
Welding parameters: display and navigation	74
Welding parameters for TIG.....	74
Welding parameters for rod electrodes.....	77
Preparation	79
Welding job	80

Finishing the welding job.....	82
Saving settings as a job	84
General	84
Preparation	84
Saving settings as a job	85
Finish saving job	90

Setup settings 93

The Setup menu	95
General	95
Overview	95
TIG setup	96
Opening the TIG setup.....	96
Changing welding parameters	97
Exiting TIG setup	98
Welding parameters in the TIG setup	99
TIG setup 2nd	101
Opening the TIG setup 2nd.....	101
Changing welding parameters	101
Exiting TIG setup 2nd	102
Welding parameters in the TIG setup 2nd	104
AC setup	107
General	107
Open the AC setup	107
Changing welding parameters	108
Exiting AC setup	109
Welding parameters in AC setup	110
AC setup 2nd	112
General	112
Opening the AC setup 2nd.....	112
Changing welding parameters	112
Exiting AC setup 2nd	113
Welding parameters in AC setup 2nd	115
Gas setup.....	116
General	116
Opening the gas setup.....	116
Changing welding parameters	117
Exiting gas setup.....	118
Gas setup parameters	119
Cold wire setup	122
General	122
Opening the AC setup.....	122
Changing welding parameters	123
Exiting the cold wire setup	124
Welding parameters in the cold wire setup	125
Calibrating push-pull unit	127
General	127
Calibrating the push-pull unit	127
General	129
Service codes during calibration of the push-pull unit.....	129
Rod elec. setup (rod electrode setup).....	133
Open the rod electrode setup	133
Changing welding parameters	134
Exiting rod electrode-setup	135
Rod electrode setup parameters:.....	135
Rod elec. setup 2nd (rod electrode setup 2nd).....	137
Opening the rod electrode setup 2nd.....	137
Changing welding parameters	137
Exiting rod electrode setup 2nd	138
Rod electrode setup 2nd welding parameters	140
AC setup (for rod electrodes).....	143
General	143
Opening the AC setup.....	143

Changing welding parameters	144
Exiting AC setup	144
Welding parameters in AC setup	145
Job	146
General	146
Opening the Job set-up menu.....	146
Save / retrieve	146
Overview	146
Optimising a job	147
Optimising a job	147
Renaming a job.....	149
Finish optimising job	151
Adjustable TIG parameters	152
Adjustable rod electrode parameters	157
Deleting a job	161
Deleting a job	161
Basic setting.....	164
General	164
Opening the basic settings.....	164
Changing welding parameters	165
Exiting basic settings	166
Basic setting parameters	167
Info	168
General	168
Calling up the info screen	168
Exiting the info screen.....	169
Entries on the info screen	170
Lock keys	171
General	171
Lock keys	171
Unlock keys again	172
Factory - for resetting the welding machine	173
General	173
Factory - for resetting the welding machine	173
L/R alignment.....	175
Abbreviations	175
General information on welding circuit inductivity L	175
General information on welding circuit resistance R.....	175
L/R alignment.....	175

Troubleshooting and maintenance 179

Troubleshooting	181
General	181
Safety.....	181
Displayed service codes	181
Service codes displayed in conjunction with the digital gas control option	187
Displayed Service codes in conjunction with cold wire-feed unit	187
Power source - troubleshooting	188
Care, maintenance and disposal	190
General	190
Safety.....	190
At every start-up.....	190
Every 2 months	190
Every 6 months	191
Disposal	191

Appendix 193

Technical data.....	195
Special voltages.....	195
MagicWave2200 Comfort	195
MagicWave2500 / 3000 Comfort	196
MagicWave 2500 / 3000 Comfort MV	196

MagicWave 4000 Comfort, MagicWave 4000 Comfort MV	198
MagicWave 5000 Comfort, MagicWave 5000 Comfort MV	198
TransTig 2200 Comfort	199
TransTig2500 / 3000 Comfort	200
TransTig 2500 / 3000 Comfort MV	201
TransTig 4000 Comfort, TransTig 4000 Comfort MV	202
TransTig 5000 Comfort, TransTig 5000 Comfort MV	203
Explanation of footnotes	204

Safety rules

Explanation of safety notices



DANGER!

Indicates immediate danger.

- If not avoided, death or serious injury will result.



WARNING!

Indicates a potentially hazardous situation.

- If not avoided, death or serious injury may result.



CAUTION!

Indicates a situation where damage or injury could occur.

- If not avoided, minor injury and/or damage to property may result.

NOTE!

Indicates a risk of flawed results and possible damage to the equipment.

General

The device is manufactured using state-of-the-art technology and according to recognised safety standards. If used incorrectly or misused, however, it can cause:

- injury or death to the operator or a third party,
- damage to the device and other material assets belonging to the operating company,
- inefficient operation of the device.

All persons involved in commissioning, operating, maintaining and servicing the device must:

- be suitably qualified,
- have sufficient knowledge of welding and
- read and follow these operating instructions carefully.

The operating instructions must always be at hand wherever the device is being used. In addition to the operating instructions, attention must also be paid to any generally applicable and local regulations regarding accident prevention and environmental protection.

All safety and danger notices on the device

- must be in a legible state,
- must not be damaged,
- must not be removed,
- must not be covered, pasted or painted over.

For the location of the safety and danger notices on the device, refer to the section headed "General" in the operating instructions for the device.

Before switching on the device, rectify any faults that could compromise safety.

This is for your personal safety!

Proper use

The device is to be used exclusively for its intended purpose.

The device is intended solely for the welding processes specified on the rating plate. Any use above and beyond this purpose is deemed improper. The manufacturer shall not be held liable for any damage arising from such usage.

Proper use includes:

- carefully reading and following all the instructions given in the operating instructions
 - studying and obeying all safety and danger notices carefully
 - performing all stipulated inspection and maintenance work.
-

Never use the device for the following purposes:

- Thawing out pipes
 - Charging batteries
 - Starting engines
-

The device is designed for use in industry and the workshop. The manufacturer accepts no responsibility for any damage caused through use in a domestic setting.

The manufacturer likewise accepts no liability for inadequate or incorrect results.

Environmental conditions

Operation or storage of the device outside the stipulated area will be deemed as not in accordance with the intended purpose. The manufacturer shall not be held liable for any damage arising from such usage.

Ambient temperature range:

- during operation: -10 °C to + 40 °C (14 °F to 104 °F)
 - during transport and storage: -20 °C to +55 °C (-4 °F to 131 °F)
-

Relative humidity:

- up to 50% at 40 °C (104 °F)
 - up to 90% at 20 °C (68 °F)
-

The surrounding air must be free from dust, acids, corrosive gases or substances, etc. Can be used at altitudes of up to 2000 m (6561 ft. 8.16 in.)

Obligations of the operator

The operator must only allow persons to work with the device who:

- are familiar with the fundamental instructions regarding safety at work and accident prevention and have been instructed in how to use the device
 - have read and understood these operating instructions, especially the section "safety rules", and have confirmed as much with their signatures
 - are trained to produce the required results.
-

Checks must be carried out at regular intervals to ensure that operators are working in a safety-conscious manner.

Obligations of personnel

Before using the device, all persons instructed to do so undertake:

- to observe the basic instructions regarding safety at work and accident prevention
 - to read these operating instructions, especially the "Safety rules" section and sign to confirm that they have understood them and will follow them.
-

Before leaving the workplace, ensure that people or property cannot come to any harm in your absence.

Mains connection

Devices with a higher rating may affect the energy quality of the mains due to their current consumption.

This may affect a number device types in terms of:

- Connection restrictions
- Criteria with regard to the maximum permissible mains impedance ^{*)}
- Criteria with regard to the minimum short-circuit power requirement ^{*)}

^{*)} at the interface with the public grid
see "Technical data"

In this case, the plant operator or the person using the device should check whether the device may be connected, where appropriate by discussing the matter with the power supply company.

IMPORTANT! Ensure that the mains connection is earthed properly

Protecting yourself and others

Anyone working with the device exposes themselves to numerous risks, e.g.

- flying sparks and hot pieces of metal
- Arc radiation, which can damage eyes and skin
- Hazardous electromagnetic fields, which can endanger the lives of those using cardiac pacemakers
- Risk of electrocution from mains current and welding current
- Greater noise pollution
- Harmful welding fumes and gases

Suitable protective clothing must be worn when working with the device. The protective clothing must have the following properties:

- Flame-resistant
- Insulating and dry
- Covers the whole body, is undamaged and in good condition
- Safety helmet
- Trousers with no turn-ups

Protective clothing refers to a variety of different items. Operators should:

- Protect eyes and face from UV rays, heat and sparks using a protective visor and regulation filter
- Wear regulation protective goggles with side protection behind the protective visor
- Wear stout footwear that provides insulation even in wet conditions
- Protect the hands with suitable gloves (electrically insulated and providing protection against heat)
- Wear ear protection to reduce the harmful effects of noise and to prevent injury

Keep all persons, especially children, out of the working area while any devices are in operation or welding is in progress. If, however, there are people in the vicinity:

- Make them aware of all the dangers (risk of dazzling by the arc, injury from flying sparks, harmful welding fumes, noise, possible risks from mains current and welding current, etc.)
- Provide suitable protective equipment
- Alternatively, erect suitable safety screens/curtains.

Noise emission values

The device generates a maximum sound power level of <80 dB(A) (ref. 1pW) when idling and in the cooling phase following operation at the maximum permissible operating point under maximum rated load conditions according to EN 60974-1.

It is not possible to provide a workplace-related emission value during welding (or cutting) as this is influenced by both the process and the environment. All manner of different welding parameters come into play, including the welding process (MIG/MAG, TIG welding), the type of power selected (DC or AC), the power range, the type of weld metal, the resonance characteristics of the workpiece, the workplace environment, etc.

Danger from toxic gases and vapours

The fumes produced during welding contain harmful gases and vapours.

Welding fumes contain substances that can cause cancer, as stated in Monograph 118 of the International Agency for Research on Cancer.

Use at-source extraction and a room extraction system.

If necessary, use a welding torch with an integrated extraction device.

Keep your face away from welding fumes and gases.

Fumes and hazardous gases

- must not be breathed in
- must be extracted from the working area using appropriate methods.

Ensure an adequate supply of fresh air with a ventilation rate of at least 20 m³/hour.

Otherwise, a protective mask with an air supply must be worn.

Close the shielding gas cylinder valve or main gas supply if no welding is taking place.

If there is any doubt about whether the extraction capacity is sufficient, the measured toxic emission values should be compared with the permissible limit values.

The following components are responsible, amongst other things, for the degree of toxicity of welding fumes:

- Metals used for the workpiece
- Electrodes
- Coatings
- Cleaners, degreasers, etc.

The relevant material safety data sheets and manufacturer's specifications for the listed components should therefore be studied carefully.

Flammable vapours (e.g. solvent fumes) should be kept away from the arc's radiation area.

Danger from flying sparks

Flying sparks may cause fires or explosions.

Never weld close to flammable materials.

Flammable materials must be at least 11 metres (36 ft. 1.07 in.) away from the arc, or alternatively covered with an approved cover.

A suitable, tested fire extinguisher must be available and ready for use.

Sparks and pieces of hot metal may also get into adjacent areas through small gaps or openings. Take appropriate precautions to prevent any danger of injury or fire.

Welding must not be performed in areas that are subject to fire or explosion or near sealed tanks, vessels or pipes unless these have been prepared in accordance with the relevant national and international standards.

Do not carry out welding on containers that are being or have been used to store gases, propellants, mineral oils or similar products. Residues pose an explosive hazard.

Risks from mains current and welding current

An electric shock is potentially life threatening and can be fatal.

Do not touch live parts either inside or outside the device.

During MIG/MAG welding and TIG welding, the welding wire, the wirepool, the feed rollers and all pieces of metal that are in contact with the welding wire are live.

Always set the wirefeeder up on a sufficiently insulated surface or use a suitable, insulated wirefeeder holder.

Make sure that you and others are protected with an adequately insulated, dry temporary backing or cover for the earth or ground potential. This temporary backing or cover must extend over the entire area between the body and the earth or ground potential.

All cables and leads must be secured, undamaged, insulated and adequately dimensioned. Replace loose connections and scorched, damaged or inadequately dimensioned cables and leads immediately.

Use the handle to ensure the power connections are tight before every use.

In the case of power cables with a bayonet connector, rotate the power cable around the longitudinal axis by at least 180° and pre-load.

Do not wrap cables or leads around the body or parts of the body.

The electrode (rod electrode, tungsten electrode, welding wire, etc.) must

- never be immersed in liquid for cooling
- Never touch the electrode when the power source is switched on.

Double the open circuit voltage of a power source can occur between the welding electrodes of two power sources. Touching the potentials of both electrodes at the same time may be fatal under certain circumstances.

Arrange for the mains cable to be checked regularly by a qualified electrician to ensure the ground conductor is functioning properly.

The device must only be operated on a mains supply with a ground conductor and a socket with a ground conductor contact.

Operating the device on a grid without a ground conductor and in a socket without a ground conductor contact will be deemed gross negligence. The manufacturer shall not be held liable for any damage arising from such usage.

If necessary, provide an adequate earth connection for the workpiece.

Switch off unused devices.

Wear a safety harness if working at height.

Before working on the device, switch it off and pull out the mains plug.

Attach a clearly legible and easy-to-understand warning sign to the device to prevent anyone from plugging the mains plug back in and switching it on again.

After opening the device:

- Discharge all live components
- Ensure that all components in the device are de-energised

If work on live parts is required, appoint a second person to switch off the main switch at the right moment.

Meandering welding currents

If the following instructions are ignored, meandering welding currents can develop with the following consequences:

- Fire hazard
- Overheating of parts connected to the workpiece
- Irreparable damage to ground conductors
- Damage to device and other electrical equipment

Ensure that the workpiece is held securely by the workpiece clamp.

Attach the workpiece clamp as close as possible to the area that is to be welded.

If the floor is electrically conductive, the device must be set up with sufficient insulating material to insulate it from the floor.

If distribution boards, twin-head mounts, etc., are being used, note the following: The electrode of the welding torch / electrode holder that is not used is also live. Make sure that the welding torch / electrode holder that is not used is kept sufficiently insulated.

In the case of automated MIG/MAG applications, ensure that only an insulated wire electrode is routed from the welding wire drum, large wirefeeder spool or wirepool to the wire-feed unit.

EMC Device Classifications

Devices in emission class A:

- Are only designed for use in industrial settings
- Can cause line-bound and radiated interference in other areas

Devices in emission class B:

- Satisfy the emissions criteria for residential and industrial areas. This is also true for residential areas in which the energy is supplied from the public low-voltage mains.

EMC device classification as per the rating plate or technical data.

EMC measures

In certain cases, even though a device complies with the standard limit values for emissions, it may affect the application area for which it was designed (e.g. when there is sensitive equipment at the same location, or if the site where the device is installed is close to either radio or television receivers).

If this is the case, then the operator is obliged to take appropriate action to rectify the situation.

Check and evaluate the immunity to interference of nearby devices according to national and international regulations. Examples of equipment that may be susceptible to interference from the device include:

- Safety devices
- Power, signal and data transfer lines
- IT and telecommunications devices
- Measuring and calibrating devices

Supporting measures for avoidance of EMC problems:

1. Mains supply
 - If electromagnetic interference arises despite correct mains connection, additional measures are necessary (e.g. use a suitable line filter).
2. Welding power leads
 - must be kept as short as possible
 - must run close together (to avoid EMF problems)
 - must be kept well apart from other leads
3. Equipotential bonding
4. Earthing of the workpiece
 - If necessary, establish an earth connection using suitable capacitors.
5. Shielding, if necessary
 - Shield off other nearby devices
 - Shield off entire welding installation

EMF measures

Electromagnetic fields may pose as yet unknown risks to health:

- effects on the health of others in the vicinity, e.g. wearers of pacemakers and hearing aids
- wearers of pacemakers must seek advice from their doctor before approaching the device or any welding that is in progress
- for safety reasons, keep distances between the welding cables and the welder's head/torso as large as possible
- do not carry welding cables and hosepacks over the shoulders or wind them around any part of the body

Specific hazards

Keep hands, hair, clothing and tools away from moving parts. For example:

- Fans
- Cogs
- Rollers
- Shafts
- Wirespools and welding wires

Do not reach into the rotating cogs of the wire drive or into rotating drive components.

Covers and side panels may only be opened/removed while maintenance or repair work is being carried out.

During operation

- Ensure that all covers are closed and all side panels are fitted properly.
- Keep all covers and side panels closed.

The welding wire emerging from the welding torch poses a high risk of injury (piercing of the hand, injuries to the face and eyes, etc.).

Therefore always keep the welding torch away from the body (devices with wire-feed unit) and wear suitable protective goggles.

Never touch the workpiece during or after welding - risk of burns.

Slag can jump off cooling workpieces. The specified protective equipment must therefore also be worn when reworking workpieces, and steps must be taken to ensure that other people are also adequately protected.

Welding torches and other parts with a high operating temperature must be allowed to cool down before handling.

Special provisions apply in areas at risk of fire or explosion - observe relevant national and international regulations.

Power sources for work in areas with increased electric risk (e.g. near boilers) must carry the "Safety" sign. However, the power source must not be located in such areas.

Risk of scalding from escaping coolant. Switch off cooling unit before disconnecting coolant flow or return lines.

Observe the information on the coolant safety data sheet when handling coolant. The coolant safety data sheet may be obtained from your service centre or downloaded from the manufacturer's website.

Use only suitable load-carrying equipment supplied by the manufacturer when transporting devices by crane.

- Hook chains and/or ropes onto all suspension points provided on the load-carrying equipment.
- Chains and ropes must be at the smallest angle possible to the vertical.
- Remove gas cylinder and wire-feed unit (MIG/MAG and TIG devices).

If the wire-feed unit is attached to a crane holder during welding, always use a suitable, insulated wirefeeder hoisting attachment (MIG/MAG and TIG devices).

If the device has a carrying strap or handle, this is intended solely for carrying by hand. The carrying strap is not to be used if transporting with a crane, counterbalanced lift truck or other mechanical hoist.

All lifting accessories (straps, handles, chains, etc.) used in connection with the device or its components must be tested regularly (e.g. for mechanical damage, corrosion or changes caused by other environmental factors).

The testing interval and scope of testing must comply with applicable national standards and directives as a minimum.

Odourless and colourless shielding gas may escape unnoticed if an adapter is used for the shielding gas connection. Prior to assembly, seal the device-side thread of the adapter for the shielding gas connection using suitable Teflon tape.

Requirement for the shielding gas

Especially with ring lines, contaminated shielding gas can cause damage to equipment and reduce welding quality.

Meet the following requirements regarding shielding gas quality:

- Solid particle size < 40 µm
 - Pressure condensation point < -20 °C
 - Max. oil content < 25 mg/m³
-

Use filters if necessary.

Danger from shielding gas cylinders

Shielding gas cylinders contain gas under pressure and can explode if damaged. As the shielding gas cylinders are part of the welding equipment, they must be handled with the greatest of care.

Protect shielding gas cylinders containing compressed gas from excessive heat, mechanical impact, slag, naked flames, sparks and arcs.

Mount the shielding gas cylinders vertically and secure according to instructions to prevent them falling over.

Keep the shielding gas cylinders well away from any welding or other electrical circuits.

Never hang a welding torch on a shielding gas cylinder.

Never touch a shielding gas cylinder with an electrode.

Risk of explosion - never attempt to weld a pressurised shielding gas cylinder.

Only use shielding gas cylinders suitable for the application in hand, along with the correct and appropriate accessories (regulator, hoses and fittings). Only use shielding gas cylinders and accessories that are in good condition.

Turn your face to one side when opening the valve of a shielding gas cylinder.

Close the shielding gas cylinder valve if no welding is taking place.

If the shielding gas cylinder is not connected, leave the valve cap in place on the cylinder.

The manufacturer's instructions must be observed as well as applicable national and international regulations for shielding gas cylinders and accessories.

Danger from escaping shielding gas

Risk of suffocation from the uncontrolled escape of shielding gas

Shielding gas is colourless and odourless and, in the event of a leak, can displace the oxygen in the ambient air.

- Ensure an adequate supply of fresh air with a ventilation rate of at least 20 m³/hour.
- Observe safety and maintenance instructions on the shielding gas cylinder or the main gas supply.
- Close the shielding gas cylinder valve or main gas supply if no welding is taking place.
- Check the shielding gas cylinder or main gas supply for uncontrolled gas leakage before every start-up.

Safety measures at the installation location and during transport

A device toppling over could easily kill someone. Place the device on a solid, level surface such that it remains stable

- The maximum permissible tilt angle is 10°.

Special regulations apply in rooms at risk of fire or explosion

- Observe relevant national and international regulations.

Use internal directives and checks to ensure that the workplace environment is always clean and clearly laid out.

Only set up and operate the device in accordance with the degree of protection shown on the rating plate.

When setting up the device, ensure there is an all-round clearance of 0.5 m (1 ft. 7.69 in.) to ensure that cooling air can flow in and out freely.

When transporting the device, observe the relevant national and local guidelines and accident prevention regulations. This applies especially to guidelines regarding the risks arising during transport.

Do not lift or transport operational devices. Switch off devices before transport or lifting.

Before transporting the device, allow coolant to drain completely and detach the following components:

- Wirefeeder
- Wirespool
- Shielding gas cylinder

After transporting the device, the device must be visually inspected for damage before commissioning. Any damage must be repaired by trained service technicians before commissioning the device.

Safety measures in normal operation

Only operate the device when all safety devices are fully functional. If the safety devices are not fully functional, there is a risk of

- injury or death to the operator or a third party
- damage to the device and other material assets belonging to the operator
- inefficient operation of the device

Any safety devices that are not functioning properly must be repaired before switching on the device.

Never bypass or disable safety devices.

Before switching on the device, ensure that no one is likely to be endangered.

Check the device at least once a week for obvious damage and proper functioning of safety devices.

Always fasten the shielding gas cylinder securely and remove it beforehand if the device is to be transported by crane.

Only the manufacturer's original coolant is suitable for use with our devices due to its properties (electrical conductivity, anti-freeze agent, material compatibility, flammability, etc.).

Only use suitable original coolant from the manufacturer.

Do not mix the manufacturer's original coolant with other coolants.

Only connect the manufacturer's system components to the cooling circuit.

The manufacturer accepts no liability for damage resulting from use of other system components or a different coolant. In addition, all warranty claims will be forfeited.

Cooling Liquid FCL 10/20 does not ignite. The ethanol-based coolant can ignite under certain conditions. Transport the coolant only in its original, sealed containers and keep well away from any sources of ignition.

Used coolant must be disposed of properly in accordance with the relevant national and international regulations. The coolant safety data sheet may be obtained from your service centre or downloaded from the manufacturer's website.

Check the coolant level before starting to weld, while the system is still cool.

Commissioning, maintenance and repair

It is impossible to guarantee that bought-in parts are designed and manufactured to meet the demands made of them, or that they satisfy safety requirements.

- Use only original spare and wearing parts (also applies to standard parts).
- Do not carry out any modifications, alterations, etc. to the device without the manufacturer's consent.
- Components that are not in perfect condition must be replaced immediately.
- When ordering, please give the exact designation and part number as shown in the spare parts list, as well as the serial number of your device.

The housing screws provide the ground conductor connection for earthing the housing parts.

Only use original housing screws in the correct number and tightened to the specified torque.

Safety inspection

The manufacturer recommends that a safety inspection of the device is performed at least once every 12 months.

The manufacturer recommends that the power source be calibrated during the same 12-month period.

A safety inspection should be carried out by a qualified electrician

- after any changes are made
- after any additional parts are installed, or after any conversions
- after repair, care and maintenance has been carried out
- at least every twelve months.

For safety inspections, follow the appropriate national and international standards and directives.

Further details on safety inspection and calibration can be obtained from your service centre. They will provide you on request with any documents you may require.

Disposal

Do not dispose of this device with normal domestic waste! To comply with the European Directive on Waste Electrical and Electronic Equipment and its implementation as national law, electrical equipment that has reached the end of its life must be collected separately and returned to an approved recycling facility. Any device that you no longer require must

either be returned to your dealer or given to one of the approved collection and recycling facilities in your area. Ignoring this European Directive may have potentially adverse effects on the environment and your health!

Safety symbols

Devices with the CE mark satisfy the essential requirements of the low-voltage and electromagnetic compatibility directives (e.g. relevant product standards of the EN 60 974 series).

Fronius International GmbH hereby declares that the device is compliant with Directive 2014/53/EU. The full text on the EU Declaration of Conformity can be found at the following address: <http://www.fronius.com>

Devices marked with the CSA test mark satisfy the requirements of the relevant standards for Canada and the USA.

Data protection

The user is responsible for the safekeeping of any changes made to the factory settings. The manufacturer accepts no liability for any deleted personal settings.

Copyright

Copyright of these operating instructions remains with the manufacturer.

The text and illustrations are all technically correct at the time of printing. We reserve the right to make changes. The contents of the operating instructions shall not provide the basis for any claims whatsoever on the part of the purchaser. If you have any suggestions for improvement, or can point out any mistakes that you have found in the instructions, we will be most grateful for your comments.

General information

Device concept



The MagicWave (MW) 2200 / 2500 / 3000 / 4000 / 5000 Comfort and TransTig (TT) 2200 / 2500 / 3000 / 4000 / 5000 Comfort TIG power sources are completely digitised, microprocessor-controlled inverter power sources.

Their modular design and potential for system add-ons ensure a high degree of flexibility. The devices can be adapted to any situation.

The power sources are generator-compatible. They are exceptionally sturdy in day-to-day operation thanks to the protected control elements and their powder-coated housings.

The TIG pulsed arc function, with its wide frequency range, is available on both the MagicWave and TransTig.

To optimise the ignition sequence in TIG AC welding, the MagicWave takes into account not only the diameter of the electrode, but also its current temperature, calculated with reference to the preceding welding time and welding off-time.

RPI (**R**everse **P**olarity **I**gnition) ensures an excellent ignition response during TIG DC welding.

Functional principle

The central control and regulation unit of the power sources is coupled with a digital signal processor. The central control and regulation unit and signal processor control the entire welding process.

During the welding process, the actual data is measured continuously and the device responds immediately to any changes. Control algorithms ensure that the desired target state is maintained.

This results in:

- a precise welding process,
- exact reproducibility of all results
- excellent weld properties.

Application areas

The devices are used in workshops and industry for manual and automated TIG applications with unalloyed and low-alloy steel and high-alloy chrome-nickel steels.


The MagicWave power sources perform exceptionally well when it comes to welding aluminium, aluminium alloys and magnesium due to the variable AC frequency.

System components

General

The TransTig and MagicWave power sources can be used with a wide variety of system add-ons and options.

Overview



System add-ons and options

Item	Description
(1)	TIG robot welding torch Cold wire feeders with wire drive
(2)	Power sources
(3)	Cooling units
(4)	Trolley with gas cylinder holder
(5)	Pedal remote control unit
(6)	Cold wire-feed unit
(7)	TIG welding torch Standard / Up/Down
(8)	JobMaster TIG welding torch
(9)	Remote control units and robot accessories
(10)	Grounding (earthing) cable
(11)	Electrode cable

Control elements and connections

Description of the control panels

General

NOTE!

Due to software updates, you may find that your device has certain functions that are not described in these operating instructions or vice versa.

Individual illustrations may also differ slightly from the actual controls on your device, but these controls function in exactly the same way.

Safety




WARNING!

Danger from incorrect operation.

Possible serious injury and damage to property.













- ▶ Do not use the functions described here until you have read and completely understood these Operating Instructions.
- ▶ Do not use the functions described here until you have fully read and understood all of the Operating Instructions for the system components, in particular the safety rules!

MagicWave Comfort control panel




No. Function







(1)	Pulse indicator lights up when the F-P set-up parameter has been set to a pulse frequency	
(2)	Spot welding indicator lights up when the SPT set-up parameter has been set to a spot welding time	
(3)	Cold wire-feed unit indicator lights up when a cold wire-feed unit is connected	
(4)	Display	
(5)	Tacking indicator lights up when the tAC set-up parameter has been set to a period of time	




No.	Function	
(6)	Electrode overload indicator lights up if the tungsten electrode is overloaded See section on TIG welding in Chapter "Welding mode" for more information on the electrode overload indicator.	
(7)	Keylock indicator lights up when the keylock is activated	
(8)	Process button for selecting the welding process depending on the mode that has been chosen	
	2-step mode/4-step mode:	
	 automatic cap-shaping; only available in conjunction with TIG AC welding	
	 TIG AC welding process	
	 TIG DC- welding process	
	Manual metal arc welding mode:	
	 MMA AC welding process	
	 MMA DC- welding process	
	 MMA DC+ welding process	
	When a process is selected, the LED on the relevant symbol lights up.	
(9)	Right arrow key for navigating in the menu	
(10)	Mode button for selecting the mode	
	 2-step mode	
	 4-step mode	
	 Manual metal arc welding	
	When a mode is selected, the LED on the relevant symbol lights up.	
(11)	Gas test button for setting the required shielding gas flow rate on the gas pressure regulator After pressing this button, gas flows for 30 seconds. Press the button again to stop the gas flow prematurely.	
(12)	Adjusting dial <ul style="list-style-type: none"> - Turn the adjusting dial to: select welding parameter - Press the adjusting dial to: confirm a selection in a menu, accept values 	
(13)	Menu button for calling up the menu in the selected process	
(14)	Left arrow key for navigating in the menu	
(15)	HF (high frequency) ignition indicator lights up when the HF ignition welding parameter has been set to an interval for the high frequency pulses	

**TransTig
Comfort control
panel**



No. Function


- | | | |
|------|---|---|
| (1) | Pulse indicator
lights up when the F-P set-up parameter has been set to a pulse frequency |  |
| (2) | Spot welding indicator
lights up when the SPt set-up parameter has been set to a spot welding time |  |
| (3) | Cold wire-feed unit indicator
lights up when a cold wire-feed unit is connected |  |
| (4) | Display | |
| (5) | Tacking indicator
lights up when the tAC set-up parameter has been set to a period of time |  |
| (6) | Electrode overload indicator
lights up if the tungsten electrode is overloaded
See section on TIG welding in Chapter "Welding mode" for more information on the electrode overload indicator. |  |
| (7) | Keylock indicator
lights up when the keylock is activated |  |
| (8) | Right arrow key
for navigating in the menu | |
| (9) | Mode button
for selecting the mode

<div style="display: flex; align-items: center;">  2-step mode
  4-step mode
  Manual metal arc welding </div>
When a mode is selected, the LED on the relevant symbol lights up. | |
| (10) | Gas test button
for setting the required shielding gas flow rate on the gas pressure regulator
After pressing this button, gas flows for 30 seconds. Press the button again to stop the gas flow prematurely. | |
| (11) | Adjusting dial <ul style="list-style-type: none"> - Turn the adjusting dial to: select welding parameter - Press the adjusting dial to: confirm a selection in a menu, accept values | |
| (12) | Menu button
for calling up the menu in the selected process | |


No.	Function	
(13)	Left arrow key for navigating in the menu	
(14)	HF (high frequency) ignition indicator lights up when the HF ignition welding parameter has been set to an interval for the high frequency pulses	HF

Connections, switches and mechanical components

MagicWave 2200 Comfort




MagicWave 2200 Comfort - front




MagicWave 2200 Comfort - rear

No.	Function
(1)	Welding torch connection for connecting: - the TIG welding torch - the electrode cable for manual metal arc welding
(2)	LocalNet connection standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)
(3)	Handle
(4)	Torch control connection - for connecting the control plug of a conventional welding torch - input for the collision protection signal when a robot interface or field bus coupler is connected
(5)	Grounding (earthing) cable connection for connecting the grounding (earthing) cable
(6)	Shielding gas connection
(7)	Mains switch for switching the power source on and off
(8)	Mains cable with strain relief device

**MagicWave
2500 / 3000 Com-
fort**




MagicWave 2500 / 3000 Comfort - front




MagicWave 2500 / 3000 Comfort - rear

No.	Function
(1)	Grounding (earthing) cable connection for connecting the grounding (earthing) cable
(2)	LocalNet connection standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)
(3)	Handle
(4)	Torch control connection <ul style="list-style-type: none"> - for connecting the control plug of a conventional welding torch - input for the collision protection signal when a robot interface or field bus coupler is connected
(5)	Welding torch connection for connecting: <ul style="list-style-type: none"> - the TIG welding torch - the electrode cable for manual metal arc welding
(6)	Shielding gas connection
(7)	Mains cable with strain relief device
(8)	Mains switch for switching the power source on and off

**MagicWave
4000 / 5000 Com-
fort**



MagicWave 4000 / 5000 Comfort - front



MagicWave 4000 / 5000 Comfort - rear

No.	Function
(1)	Mains switch to switch the power source on and off
(2)	Welding torch connection for connecting the TIG welding torch
(3)	Electrode holder connection for connecting the electrode cable for manual metal arc welding
(4)	Torch control connection <ul style="list-style-type: none"> - for connecting the control plug of a conventional welding torch - input for the collision protection signal when a robot interface or field bus coupler is connected
(5)	LocalNet connection standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)
(6)	Grounding cable connection for connecting the grounding cable
(7)	Blanking covers reserved for LocalNet connection
(8)	Mains cable with strain relief device
(9)	Shielding gas connection


- for connecting the control plug of a conventional welding torch
- input for the collision protection signal when a robot interface or field bus coupler is connected

standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)


for connecting the grounding cable

reserved for LocalNet connection

**TransTig
2200 Comfort**




TransTig 2200 Comfort - front




TransTig 2200 Comfort - rear

No.	Function
(1)	(+) current socket with bayonet latch for connecting <ul style="list-style-type: none"> - the grounding (earthing) cable when TIG welding - the electrode cable or grounding (earthing) cable during MMA welding (depending on the type of electrode)
(2)	LocalNet connection standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)
(3)	Handle
(4)	Torch control connection <ul style="list-style-type: none"> - for connecting the control plug of a conventional welding torch - input for the collision protection signal when a robot interface or field bus coupler is connected
(5)	(-) current socket with bayonet latch for connecting <ul style="list-style-type: none"> - the TIG welding torch - the electrode cable or grounding (earthing) cable during MMA welding (depending on electrode type)
(6)	Shielding gas connection
(7)	Mains switch for switching the power source on and off
(8)	Mains cable with strain relief device

**TransTig
2500 / 3000 Com-
fort**




TransTig 2500 / 3000 Comfort - front




TransTig 2500 / 3000 Comfort - rear

No.	Function
(1)	(+) current socket with bayonet latch for connecting <ul style="list-style-type: none"> - the grounding (earthing) cable when TIG welding - the electrode cable or grounding (earthing) cable during MMA welding (depending on electrode type)
(2)	LocalNet connection standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)
(3)	Handle
(4)	Torch control connection <ul style="list-style-type: none"> - for connecting the control plug of a conventional welding torch - input for the collision protection signal when a robot interface or field bus coupler is connected
(5)	(-) current socket with bayonet latch for connecting <ul style="list-style-type: none"> - the TIG welding torch - the electrode cable or grounding (earthing) cable during MMA welding (depending on electrode type)
(6)	Shielding gas connection
(7)	Mains cable with strain relief device
(8)	Mains switch for switching the power source on and off

**TransTig
4000 / 5000 Com-
fort**



TransTig 4000 / 5000 Comfort - front



TransTig 4000 / 5000 Comfort - rear

No.	Function
(1)	(+) current socket with bayonet latch for connecting <ul style="list-style-type: none"> - the grounding cable when TIG welding - the electrode cable or grounding cable during MMA welding (depending on the type of electrode)
(2)	LocalNet connection standardised connection socket for system add-ons (e.g. remote control, JobMaster TIG welding torch, etc.)
(3)	Torch control connection <ul style="list-style-type: none"> - for connecting the control plug of a conventional welding torch - input for the collision protection signal when a robot interface or field bus coupler is connected
(4)	(-) current socket with bayonet latch for connecting <ul style="list-style-type: none"> - the TIG welding torch - the electrode cable or grounding cable during MMA welding (depending on the type of electrode)
(5)	Mains switch for switching the power source on and off OFF = - O - ON = - I -
(6)	Blanking covers reserved for LocalNet connection
(7)	Mains cable with strain relief device
(8)	Shielding gas connection

Installation and commissioning

Minimum equipment needed for welding task

General

Depending on which welding process you intend to use, a certain minimum equipment level will be needed in order to work with the power source.

The welding processes and the minimum equipment levels required for the welding task are then described.

TIG AC welding

- MagicWave power source
- Grounding (earthing) cable
- TIG welding torch with rocker switch
- Gas connection (shielding gas supply), with pressure regulator
- Filler metals (as required by the application)

TIG DC welding

- Power source
- Grounding (earthing) cable
- TIG welding torch with rocker switch
- Gas connection (shielding gas supply)
- Filler metals (as required by the application)

Automated TIG welding

- Power source
- Robot interface or field bus connection
- Grounding (earthing) cable
- TIG machine welding torch or TIG robot welding torch
(a cooling unit is also required with water-cooled machine or robot welding torches)
- Gas connection (shielding gas supply)
- Cold wire-feed unit and filler metals (as required by the application)

MMA welding

- Power source
- Grounding (earthing) cable
- Electrode holder
- Rod electrodes (as required by the application)

Before installation and commissioning

Safety



WARNING!

Danger due to incorrect operation and incorrectly performed work.

This can result in severe personal injury and damage to property.

- ▶ All the work and functions described in this document must only be carried out and used by trained and qualified personnel.
 - ▶ Fully read and understand this document.
 - ▶ Fully read and understand all the Operating Instructions for the system components, especially the safety rules.
-

Utilisation for intended purpose

The power source is intended exclusively for TIG and MMA welding.

Utilisation for any other purpose, or in any other manner, shall be deemed to be not in accordance with the intended purpose.

The manufacturer shall not be liable for any damage resulting from such improper use.

Proper use also includes:

- following all the information in the operating instructions
 - carrying out all the specified inspection and servicing work
-

Setup regulations

The device is tested to IP 23 protection, meaning:

- Protection against penetration by solid foreign bodies with diameters > 12.5 mm (0.49 in.)
- Protection against spraywater at any angle up to 60° to the vertical

The device can be set up and operated outdoors in accordance with degree of protection IP 23.

Avoid direct wetting (e.g. from rain).



WARNING!

Toppling or falling devices can cause life-threatening injuries.

- ▶ Place devices on a solid, level surface so that they remain stable.
-

The venting duct is a very important safety device. When choosing the installation location, ensure that the cooling air can enter and exit unhindered through the air ducts on the front and back of the device. Electroconductive metallic dust (e.g. from grinding work) must not be allowed to get sucked into the device.

Mains connection

The devices are designed for the mains voltage specified on the rating plate. If your version of the appliance does not come with mains cables and plugs ready-fitted, these must be fitted in accordance with national regulations and standards. For details of fuse protection of the mains lead, please see the technical data.



CAUTION!

An inadequately dimensioned electrical installation can cause serious damage.

- The mains lead and its fuse must be dimensioned to suit the local power supply. The technical data shown on the rating plate applies.
-

Start-up

Safety



WARNING!

An electric shock can be fatal.

If the device is plugged into the mains during installation, there is a high risk of very serious injury and damage.

- ▶ Only carry out work on the device if the mains switch is in the "O" position.
 - ▶ Only carry out work on the charger when it has been disconnected from the mains supply.
-

Remarks on the cooling unit

We recommend using a cooling unit for the following applications and situations:

- JobMaster TIG welding torch
- Robot welding
- Hosepacks over 5 m long
- TIG AC welding
- In general, where welding is performed in higher power ranges

The cooling unit is powered from the power source. The cooling unit is ready for operation when the mains switch of the power source is in the "I" position.

More information on the cooling unit can be found in the operating instructions for the cooling unit.

General

This section describes how to commission the power source:

- for the main TIG welding application
- with reference to a standard configuration for a TIG welding device.

The standard configuration consists of the following system components:

- power source
- cooling unit
- TIG manual welding torch
- pressure regulator
- gas cylinder
- gas cylinder holder
- trolley

The steps set out below provide an overview of how to commission the power source. For detailed information about the individual steps, please refer to the operating instructions for the system components.

Connecting the gas cylinder



WARNING!

If gas cylinders topple over, there is a risk of very serious injury and damage.

- ▶ Place gas cylinders on a solid, level surface in such a way that they remain stable
- ▶ Secure gas cylinders to prevent them from toppling over: fix the safety strap at the same height as the top part of the cylinder
- ▶ Never fix the safety strap around the neck of the cylinder

Follow the gas cylinder manufacturer's safety instructions.

- 1 Secure the gas cylinder
- 2 Take the protective cap off the gas cylinder
- 3 Briefly open the gas cylinder valve to remove any dust or dirt
- 4 Check the seal on the pressure regulator
- 5 Screw the pressure regulator onto the gas cylinder and tighten it

When using a TIG welding torch with an integral gas connector:

- 6 Use the gas hose to connect the pressure regulator to the shielding gas connection on the rear of the power source
- 7 Tighten the union nut on the gas hose

When using a TIG welding torch with no integral gas connector:

- 6 Connect the TIG welding torch gas hose to the pressure regulator

Establishing a ground (earth) connection to the workpiece

- 1 Move the mains switch to the O position
- 2 Plug the grounding (earthing) cable in and latch it
 - for MagicWave: in the grounding (earthing) cable connection
 - for TransTig: in the (+) current socket
- 3 Use the other end of the grounding (earthing) cable to establish a connection to the workpiece

Connecting the welding torch

CAUTION!

Risk of damage from high frequencies.

- Do not use the JobMaster TIG welding torch with a LocalNet distributor.

- 1 Move the mains switch to the "O" position
- 2 Plug in the TIG welding torch welding power-lead and latch it by turning it clockwise:
 - for MagicWave: in the welding torch connection
 - for TransTig: in the (-) current socket
- 3 Plug the welding torch control plug into the torch control connection and latch it
or
connect the control line of the JobMaster TIG welding torch to the LocalNet connection

NOTE!

Do not use pure tungsten electrodes (colour-coded green) on TransTig power sources.

- 4 Set up the welding torch in accordance with the welding torch Operating Instructions
- 5 Only when using a water-cooled torch and cooling unit:
Plug in the welding torch water connections to the water flow (black) and return (red) connections on the cooling unit.

Welding

TIG modes

Safety



WARNING!






Danger from incorrect operation.

Possible serious injury and damage to property.

- Do not use the functions described here until you have read and completely understood these Operating Instructions.
- Do not use the functions described here until you have fully read and understood all of the Operating Instructions for the system components, in particular the safety rules!

See the "The Setup menu" section for information on the settings, setting range and units of measurement of the available welding parameters.

Symbols and their explanations



GPr

Gas pre-flow time

I_s

Starting-current phase: the temperature is raised gently at low welding current, so that the filler metal can be positioned correctly

t_{up}

Upslope phase: the starting current is continuously increased until it reaches the main current (welding current) I₁

I₁

Main current phase (welding-current phase): uniform thermal input into the base material, whose temperature is raised by the advancing heat

G-H

Gas post-flow time at maximum welding current

SPt

Spot welding time

I_E

Final current phase: to prevent any local overheating of the base material due to heat build-up towards the end of welding. This eliminates any risk of weld seam drop-through.

t_{down}

Downslope phase: the welding current is continuously lowered until it reaches the end-crater current.

I₂

Reduced current phase: intermediate lowering of the welding current in order to prevent any local overheating of the base material

G-L


Gas post-flow time at minimum welding current

2-step mode

- Welding: Pull back and hold the torch trigger
- End of welding: Release the torch trigger

NOTE!

To work in 2-step mode after it has been selected, the SPt setup parameter must be set to "OFF" and the spot welding indicator on the control panel must not light up.



2-step mode

■... Manual application


■... Automatic application

Spot welding

If a value has been set for the SPt set-up parameter, 2-step mode will have the spot welding mode function. The special spot welding indicator on the control panel will light up.

- Welding: briefly pull back the torch trigger
The welding time corresponds to the value set for the SPt set-up parameter.
- to end the welding process prematurely: pull the torch trigger back again

When using a pedal remote control, the spot welding time starts when the pedal remote control is operated. The power cannot be controlled using the pedal remote control.




Spot welding

4-step mode

- Start of welding with starting current I_S : Pull back and hold the torch trigger
- Welding with main current I_1 : Release the torch trigger
- Lowering to final current I_E : Pull back and hold the torch trigger
- End of welding: Release the torch trigger

NOTE!

For 4-step mode, the special 4-step (SFS) setup parameter must be set to "OFF".



4-step mode

*) Intermediate lowering


Intermediate lowering during the main current phase reduces the welding current to the specified reduced current I_2 .

- To activate intermediate lowering, push forward and hold the torch trigger
- To revert to the main current, release the torch trigger

**Special 4-step mode:
variant 1**

Variant 1 of special 4-step mode is activated, when the special 4-step (SFS) set-up parameter-is set to "1".

Briefly pull back the torch trigger to start intermediate lowering to the specified reduced current I_2 . Briefly pull back the torch trigger a second time, to restore the main current I_1 .




Special 4-step mode: Variant 1

**Special 4-step mode:
variant 2**

Variant 2 of the special 4-step mode is activated when the special 4-step SFS set-up parameter -is set to "2".

Intermediate lowering takes place in variant 2 on the basis of the selected slope values - downslope t_{down} and upslope t_{up} :

- Push forward and hold the torch trigger: the welding current continuously drops at the set downslope value until it reaches the specified reduced current I_2 . It remains at the reduced current value I_2 until the torch trigger is released.
- When the torch trigger is released: the welding current rises at the specified upslope value until it reaches the main current value I_1 .




Special 4-step mode: Variant 2

**Special 4-step
mode:
variant 3**

Variant 3 of special 4-step mode is activated when the special 4-step mode (SFS) set-up parameter -is set to "3".

In variant 3, push forward and hold the torch trigger to start intermediate lowering. Release the torch trigger to resume the main current I_1 .

When the torch trigger is pulled back, welding ends immediately without downslope and final current.




Special 4-step mode: Variant 3

**Special 4-step
mode:
variant 4**

Variant 4 of the special 4-step mode is activated when the SFS set-up parameter is set to "4".


- Welding start-up and welding: briefly pull back and release the torch trigger - the welding current will rise at the specified upslope value from the starting current I_s until it reaches the main current value I_1 .
- Push forward and hold the torch trigger for intermediate lowering
- Release the torch trigger to resume the main current I_1
- End of welding: briefly pull back and release the torch trigger



Special 4-step mode: variant 4

Cap shaping and cap overloading

Cap-shaping



- (1) Before ignition
(2) After ignition

On MagicWave power sources, an automatic cap-shaping function is available for the TIG AC welding process:

- When the TIG AC welding process is selected, activate automatic cap-shaping
- The ideal cap for the specified diameter of the tungsten electrode is formed during welding start-up. A separate cap-shaping operation on a test workpiece is not necessary.
- The automatic cap-shaping function is then reset and deactivated. The automatic cap-shaping function has to be activated separately for each tungsten electrode.

NOTE!

The automatic cap-shaping function is not necessary if a sufficiently large cap has already formed at the tip of the tungsten electrode.

Cap overloading

If the cap is overloaded, there is a risk of an excessively large cap forming on the tungsten electrode. This will negatively affect the ignition properties.



If the cap is overloaded, the "Electrode overload" indicator will light up on the control panel.

Possible causes of cap overloading:

- tungsten electrode diameter is too small
- main current value I_1 set too high
- the balance has been set too far towards "+"

Remedy:

- use a tungsten electrode with a larger diameter
- reduce the main current and/or set the balance further towards "-"

NOTE!

The "Electrode overload" indicator is fine-tuned to work with the following tungsten electrodes:

TIG AC welding: pure tungsten electrodes

TIG DC welding: ceriated electrodes

For all other electrodes, the "Electrode overload" indicator must be treated as a reference value.

TIG welding

Safety

 **WARNING!**

Danger from incorrect operation.
Possible serious injury and damage to property.

- ▶ Do not use the functions described here until you have read and completely understood these Operating Instructions.
- ▶ Do not use the functions described here until you have fully read and understood all of the Operating Instructions for the system components, in particular the safety rules!



 **WARNING!**

An electric shock can be fatal.
If the power source is connected to the mains electricity supply during installation, there is a high risk of very serious injury and damage.



- ▶ Before carrying out any work on the device make sure that the power source mains switch is in the "O" position
- ▶ Before carrying out any work on the device make sure that the power source is unplugged from the mains

Welding parameters: display and navigation



The TIG welding parameters are shown as soon as the 2-step or 4-step mode is selected.



Use the left and right arrow keys to navigate within the welding parameters.




Welding parameters for TIG



Unit	% (of main current)
Setting range	30 - 200 AC, 0 - 200 DC
Factory setting	35 AC, 50 DC

IMPORTANT! The starting current is saved separately for the TIG AC welding and TIG DC welding modes.




Upslope, 2-step mode




Upslope, 4-step mode

Unit	s
Setting range	0.0 - 9.9
Factory setting	0.1

IMPORTANT! The UpSlope is saved separately for 2-step and 4-step modes.




Main current, 2-step mode



Main current, 4-step mode


Unit	A	
Setting range	MW 2200 Comfort 3 - 220	TT 2200 Comfort 3 - 220
	MW 2500 Comfort 3 - 250	TT 2500 Comfort 3 - 250
	MW 3000 Comfort 3 - 300	TT 3000 Comfort 3 - 300
	MW 4000 Comfort 3 - 400	TT 4000 Comfort 3 - 400
	MW 5000 Comfort 3 - 500	TT 5000 Comfort 3 - 500
Factory setting	-	

IMPORTANT! On welding torches with the Up/Down function, the entire setting range can be selected while the device is idling. During welding, the main current can be corrected in steps of +/-20 A.



In the case of 4-step mode

Unit	% (of main current)
Setting range	0 - 100
Factory setting	50




DownSlope, 2-step mode




DownSlope, 4-step mode

Unit s
 Setting range 0.0 - 9.9
 Factory setting 1.0

IMPORTANT! The DownSlope is saved separately for 2-step and 4-step modes.



Final current, 2-step mode



Final current, 4-step mode

Unit % (of main current)
 Setting range 0 - 100
 Factory setting 30



only with MagicWave for the TIG AC welding process

Unit 1
 Setting range -5 - +5
 Factory setting 0

-5: highest fusing power, lowest cleaning action

+5: highest cleaning action, lowest fusing power



If cold wirefeeder option is available

Unit	m/min	ipm
Setting range	OFF / 0.1 - max.	OFF / 3.9 - max.
Factory setting	OFF	



Unit	mm	in.
Setting range	OFF - max.	OFF - max.
Factory setting	2.4	0.1

Preparation

- 1 Plug in the mains plug

CAUTION!

Risk of injury and damage from electric shock.

As soon as the mains switch is in the "I" position, the tungsten electrode of the welding torch is live.

- Ensure that the tungsten electrode does not touch any persons or electrically conductive or earthed parts (e.g. housing, etc.).



- 2 Move the mains switch to the "I" position

The starting sequence with the Fronius logo, current firmware version and Fronius internet address is displayed for approx. 1 second:




TIG welding


- 1 Press the Mode button to select the required TIG mode:

-  2-step mode
-  4-step mode

The image for the TIG welding parameter is shown on the display:






TIG welding parameters for 2-step mode (main current welding parameter selected)



TIG welding parameters for 4-step mode (main current welding parameter selected)

- 2 Only with MagicWave: Press the Mode button to select the required TIG mode:

-  AC welding process
-  AC welding process with automatic cap-shaping function
-  DC welding process

- 3 Use the right arrow key to select the relevant welding parameters
- 4 Use the adjusting dial to set the selected welding parameter to the required value
- 5 If necessary, additional welding parameters can be set in the set-up menu:
 - Press the menu key

The relevant menu is displayed:




- Use the adjusting dial to select the desired set-up menu
- Open the selected set-up menu by pressing the adjusting dial
- Use the adjusting dial to select the welding parameter
- To change the welding parameter press the adjusting dial
- Change the welding parameter value using the adjusting dial
- Press the adjusting dial
- Exit the set-up menu

NOTE!

All welding parameter set values that have been set using the adjusting dial remain stored until the next time they are changed.

This applies even if the power source is switched off and on again in the meantime.

- 6 Open the gas cylinder valve
- 7 Set the shielding gas flow rate:
 -  Press the Gas test button
 - The test gas flow lasts for a maximum of 30 seconds. Press the button again to stop the gas flow prematurely.
 - Turn the adjusting screw on the underside of the pressure regulator until the pressure gauge shows the required gas flow rate

- 8** For long hosepacks and if condensation forms when the device is left unused in a cold environment:
purge protective gas shield and set the GPU set-up parameter to a time value
- 9** Start welding (ignite the arc)

Igniting the arc

General

To ensure the best ignition sequence in the TIG AC welding process, the MagicWave power sources take account of:

- the diameter of the tungsten electrode
- the current temperature of the tungsten electrode with reference to the preceding welding and weld-off times

To ensure the ideal ignition sequence in TIG DC welding, MagicWave power sources are equipped with RPI (**R**everse **P**olarity **I**gnition).

At the start of welding, the polarity is briefly reversed. Electrons emerge from the workpiece and strike the tungsten electrode. This results in the tungsten electrode heating up rapidly which is an essential prerequisite for optimum ignition properties.

Further information on the RPI function can be found in the Chapter Set-up parameters, Section "TIG set-up 2nd".

Igniting the arc using high frequency (HF ignition)



CAUTION!

Risk of injury due to shock caused by electric shock

Although Fronius devices comply with all relevant standards, high-frequency ignition can transmit a harmless but noticeable electric shock under certain circumstances.


- ▶ Use prescribed protective clothing, especially gloves!
- ▶ Only use suitable, completely intact and undamaged TIG hosepacks!
- ▶ Do not work in damp or wet environments!
- ▶ Take special care when working on scaffolding, work platforms, in forced positions (out-of-position welding), in tight, difficult to access or exposed areas!

HF ignition is activated when a time value has been set for the HFt setup parameter. The HF ignition indicator lights up on the control panel.


HF

Compared with touchdown ignition, HF ignition eliminates the risk of contamination of the tungsten electrode and the workpiece.

Procedure for HF ignition:




- 1 Place the gas nozzle down on the ignition location so that there is a gap of approx. 2 to 3 mm (5/64 to 1/8 in.) between the tungsten electrode and the workpiece



- 2 Increase the tilt angle of the torch and actuate the torch trigger according to the mode you have selected

The arc ignites without the electrode touching down on the workpiece.




- 3 Tilt the torch back into the normal position
- 4 Carry out welding


Touchdown ignition

If the HFt setup parameter is set to OFF, HF ignition is deactivated. The welding arc is ignited by touching the workpiece with the tungsten electrode.

Procedure for igniting the arc using touchdown ignition:




- 1 Place the gas nozzle down on the ignition location so that there is a gap of approx. 2 to 3 mm (5/64 to 1/8 in.) between the tungsten electrode and the workpiece



- 2** Actuate the torch trigger

Shielding gas flows.

- 3** Gradually tilt the welding torch up until the tungsten electrode touches the workpiece



- 4** Raise the welding torch and move it into its normal position

The arc ignites.

- 5** Carry out welding

End of welding

- 1** Depending on the set mode, finish welding by releasing the torch trigger
- 2** Wait for the set gas post-flow and hold welding torch in position over the end of the weld seam

Special functions and options

Arc break watchdog function

If the arc breaks and the current does not start to flow again within the time specified in the set-up menu, the power source cuts out automatically. The service code "no | Arc" appears on the control panel.

To start the welding process again, press any key on the control panel or the torch trigger.

The settings for the arc break watchdog set-up parameter (Arc) are described in "TIG set-up 2nd" section.

Ignition time-out function

The power source has an ignition time-out function.

Once the torch trigger is pressed, gas pre-flow begins immediately. Ignition then begins. If an arc does not appear within the time specified in the set-up menu, the power source cuts out automatically. The service code "no | IGn" appears on the control panel.

"E55" is displayed on the JobMaster TIG welding torch.

To try again, press any key on the control panel or press the torch trigger.

The settings for the ignition time-out parameter (ito) are described in the "TIG set-up 2nd" section.

TIG pulsing

The welding current set at the start of welding is not always ideal for the welding process as a whole:


- if the amperage is too low, the base material will not melt sufficiently,
- if overheating occurs, the liquid weld pool may drip.

The TIG pulsing function (TIG welding with pulsing welding current) offers a remedy: a low ground current I-G rises steeply to the significantly higher pulse current I1 and, depending on the set dcY (duty cycle) time, drops back to the ground current I-G. In TIG pulsing, small sections of the welding location melt quickly and then solidify again quickly.

In manual applications using TIG pulsing, the welding wire is applied in the maximum current phase (only possible in the low frequency range: 0.25 - 5 Hz). Higher pulse frequencies are mainly used in automatic mode to stabilise the arc.

TIG pulsing is used for out-of-position welding of steel pipes or when welding thin sheets.

Mode of operation of TIG pulsing when TIG DC welding is selected:



TIG pulsing - welding current curve

Legend:

I_S	Starting current	$F-P$	Pulse frequency *)
I_E	Final current	dcY	Duty cycle
t_{up}	Upslope	$I-G$	Ground current
t_{Down}	Downslope	I_1	Main current

*) ($1/F-P$ = time interval between two pulses)


Tacking function

The tacking function is available for the TIG DC welding process.

When a time period is specified for the tAC (tacking) setup parameter, the tacking function is assigned to 2-step mode and 4-step mode. The operating sequence of the modes remains unchanged.

During this period, a pulsed welding current is present that makes the weld pool run together better when two parts are being tacked.

Mode of operation of tacking function when the TIG DC welding process is selected:



Tacking function - welding current curve

Legend:

t_{AC}	Duration of pulsed welding current for the tacking process
I_S	Starting current
I_E	Final current
t_{up}	UpSlope
t_{Down}	DownSlope
I_1	Main current

NOTE!

The following points apply to the pulsed welding current:

- ▶ The power source automatically regulates the pulsing parameters as a function of the specified main current I_1 .
- ▶ There is no need to set any pulsing parameters.

The pulsed welding current begins

- after the end of the starting-current phase I_S
- With the UpSlope phase t_{up}

Depending on what t_{AC} time has been set, the pulsed welding current may continue up to and including the final current phase I_E (t_{AC} setup parameter set to "ON").

After the t_{AC} time has elapsed, welding continues at a constant welding current, and any pulsing parameters that may have been set continue to be available.

NOTE!


To set a specified tacking time, the t_{AC} setup parameter can be combined with the SPT setup parameter (spot welding time).

TIG cold-wire welding

TIG cold-wire welding is only possible in conjunction with a cold wire- feed unit.

Mode of operation of TIG cold-wire welding at a set pulse frequency when DC welding is selected:

- a) Current waveshape
- b) Wire feed speed curve



Legend:

I_s Starting current

I_E Final current

t_{up} Upslope

t_{Down} Downslope

$Fd.1$ Wire feed speed 1

$dt1$ Delay in the start of wirefeeding from the beginning of main current phase I_1

dcY Duty cycle

$I-G$ Ground current

I_1 Main current

$F-P$ Pulse frequency ¹⁾

$Fd.2$ Wire feed speed 2

$dt2$ Delay in the end of wirefeeding from the end of main current phase I_1

¹⁾ ($1/F-P$ = time interval between 2 pulses)

Safety



WARNING!

Danger from incorrect operation.

Possible serious injury and damage to property.

- ▶ Do not use the functions described here until you have read and completely understood these Operating Instructions.
- ▶ Do not use the functions described here until you have fully read and understood all of the Operating Instructions for the system components, in particular the safety rules!



WARNING!

An electric shock can be fatal.

If the power source is connected to the mains electricity supply during installation, there is a high risk of very serious injury and damage.

- ▶ Before carrying out any work on the device make sure that the power source mains switch is in the "O" position
- ▶ Before carrying out any work on the device make sure that the power source is unplugged from the mains

Welding parameters: display and navigation


The welding parameters for manual metal arc welding are shown as soon as the manual metal arc welding mode is selected.




Use the left and right arrow keys to navigate within the welding parameters.




Welding parameters for rod electrodes



Starting current: starting current < main current ("SoftStart")




Starting current: starting current = main current




Starting current: starting current > main current ("Hot-Start")


Unit	% (of main current)
Setting range	0 - 200
Factory setting	150



Main current: starting current < main current ("SoftStart")




Main current: starting current = main current



Main current: starting current > main current ("HotStart")

Unit	A	
Setting range	MW 2200 Comfort 10 - 180	TT 2200 Comfort 10 - 180
	MW 2500 Comfort 10 - 250	TT 2500 Comfort 10 - 250
	MW 3000 Comfort 10 - 300	TT 3000 Comfort 10 - 300
	MW 4000 Comfort 10 - 400	TT 4000 Comfort 10 - 400
	MW 5000 Comfort 10 - 500	TT 5000 Comfort 10 - 500
Factory setting	-	



To obtain optimum welding results, it will sometimes be necessary to adjust the arc-force dynamic.

Unit	% (of main current)
Setting range	0 - 100
Factory setting	20
0	soft, low-spatter arc
100	harder, more stable arc

Functional principle:

at the instant of droplet transfer or in the event of a short circuit, there is a momentary rise in amperage. In order to obtain a stable arc, the welding current is temporarily increased. If the rod electrode threatens to sink into the weld pool, this measure prevents the weld pool solidifying, as well as preventing more prolonged short circuiting of the arc. This largely prevents the rod electrode from sticking.



only with MagicWave for the manual metal arc AC welding process

Unit	1
Setting range	-5 - +5
Factory setting	0

-5: highest fusing power, lowest cleaning action

+5: highest cleaning action, lowest fusing power

Preparation

- 1** Switch off cooling units (set setup parameter C-C to OFF)
- 2** Move the mains switch to the "O" position
- 3** Disconnect the mains plug
- 4** Remove the TIG welding torch
- 5** Plug the grounding cable in and latch it into place:
 - for MagicWave: in the grounding cable connection
 - for TransTig: in the (+) current socket
- 6** Use the other end of the grounding cable to establish a connection to the workpiece
- 7** Plug in the electrode cable and twist it clockwise to latch it into place:
 - for MagicWave: in the welding torch connection
 - for TransTig: in the (-) current socket

- 8 Plug in the mains plug

⚠ CAUTION!

Risk of injury and damage from electric shock.

As soon as the mains switch is in the "I" position, the rod electrode in the electrode holder is live.

- Make sure that the rod electrode does not touch any persons or electrically conductive or earthed parts (e.g. the housing, etc.).

- 9 Move the mains switch to the "I" position

The starting sequence with the Fronius logo, current firmware version and Fronius internet address is displayed for approx. 1 second:



MMA welding


- 1 Press the Mode button to select:



NOTE!

If the MMA welding mode is selected, the welding voltage will only be available after a 3-second delay.

The image for the rod electrode welding parameter is shown on the display:



- 2 Only for MagicWave: press the process button to select the required welding process:



MMA AC welding process



MMA DC- welding process



MMA DC+ welding process

NOTE!

The TransTig power source has no switchover facility between the MMA DC- and MMA DC+ welding processes.

Procedure with TransTig power source for switching from MMA DC- welding to MMA DC+ welding:

- a) Move the mains switch to the "O" position
- b) Disconnect the mains plug
- c) Reconnect the electrode holder and the grounding cable to the opposite current sockets (i.e. swap them over)
- d) Plug in the mains plug

CAUTION!

Risk of injury and damage from electric shock.

As soon as the mains switch is in the "I" position, the rod electrode in the electrode holder is live.

- Make sure that the rod electrode does not touch any persons or electrically conductive or earthed parts (e.g. the housing, etc.)

- e) Move the mains switch to the "I" position
The starting sequence with the Fronius logo, current firmware version and Fronius internet address is displayed for approx. 1 second:



- 3 Use the right arrow key to select the relevant welding parameters
- 4 Use the adjusting dial to set the selected welding parameter to the required value
- 5 If necessary, additional welding parameters can be set in the Setup menu:
 - Press the Menu key
 The relevant menu is displayed:



- Use the adjusting dial to select the desired Setup menu
- Open the selected Setup menu by pressing the adjusting dial
- Use the adjusting dial to select the welding parameter
- To change the welding parameter press the adjusting dial
- Change the welding parameter value using the adjusting dial
- Press the adjusting dial
- Exit the Setup menu

NOTE!

All welding parameter set values that have been set using the adjusting dial remain stored until the next time they are changed.

This applies even if the power source was switched off and on again in the interim.

- 6 Start welding


Hotstart function

To obtain optimum welding results, it will sometimes be necessary to adjust the hotstart function.

Benefits

- Improved ignition, even when using electrodes with poor ignition properties
- Better fusion of the base material in the start-up phase, meaning fewer cold-shut defects
- Largely prevents slag inclusions

For details on setting the available welding parameters, please refer to the "Rod elect. set-up 2nd" section.



Example of hotstart function

Legend

- H_{ti} Hot-current time, 0-2 s, factory setting: 0.5 s
- H_{CU} HotStart current, 0-200%, factory setting 150%
- I_1 Main current = set welding current


Function:

during the specified hot-current time (H_{ti}), the welding current I_1 is increased to the HotStart current H_{CU} .

To activate the hotstart function, the Hot-Start current H_{CU} must be > 100 .

Starting current < 100 % (SoftStart)

A starting current $< 100\%$ (SoftStart) is intended for basic electrodes. Ignition takes place at a low welding current. Once the arc is stable, the welding current continues to rise until it reaches the welding current command value.



Example with a starting current $< 100\%$ (SoftStart)

Benefits:

- Improved ignition properties for electrodes that ignite at low welding currents
- Largely prevents slag inclusions
- Reduces welding spatter

- (1) Starting current
- (2) Starting current time
- (3) Main current

The starting current time is set in the rod electrodes menu.

Anti-stick function

As the arc becomes shorter, the welding voltage may drop so far that the rod electrode will tend to stick. This may also cause the rod electrode to burn out.

Electrode burn-out is prevented by activating the anti-stick function. If the rod electrode begins to stick, the power source immediately switches the welding current off. After the rod electrode has been detached from the workpiece, the welding process can be continued without any problems.

The anti-stick function can be activated and deactivated in the "Rod elect. setup 2nd" menu.

Welding job

Safety

 **WARNING!**

Danger from incorrect operation.
Possible serious injury and damage to property.

- ▶ Do not use the functions described here until you have read and completely understood these Operating Instructions.
- ▶ Do not use the functions described here until you have fully read and understood all of the Operating Instructions for the system components, in particular the safety rules!

 **WARNING!**

An electric shock can be fatal.
If the power source is connected to the mains electricity supply during installation, there is a high risk of very serious injury and damage.

- ▶ Before carrying out any work on the device make sure that the power source mains switch is in the "O" position
- ▶ Before carrying out any work on the device make sure that the power source is unplugged from the mains


Welding parameters: display and navigation

The welding parameters for the welding job are displayed as soon as a job has been selected. LEDs on the relevant symbols are illuminated according to the method and operating mode of the chosen job.


Use the left and right arrow keys to navigate within the welding parameters.



Welding parameters for TIG




Starting current, 2-step mode



Starting current, 4-step mode

Unit	% (of main current)
Setting range	30 - 200 AC, 0 - 200 DC
Factory setting	35 AC, 50 DC

IMPORTANT! The starting current is saved separately for the TIG AC welding and TIG DC welding modes.




Upslope, 2-step mode




Upslope, 4-step mode

Unit	s
Setting range	0.0 - 9.9
Factory setting	0.1

IMPORTANT! The UpSlope is saved separately for 2-step and 4-step modes.




Main current, 2-step mode



Main current, 4-step mode


Unit	A	
Setting range	MW 2200 Comfort 3 - 220	TT 2200 Comfort 3 - 220
	MW 2500 Comfort 3 - 250	TT 2500 Comfort 3 - 250
	MW 3000 Comfort 3 - 300	TT 3000 Comfort 3 - 300
	MW 4000 Comfort 3 - 400	TT 4000 Comfort 3 - 400
	MW 5000 Comfort 3 - 500	TT 5000 Comfort 3 - 500
Factory setting	-	

IMPORTANT! On welding torches with the Up/Down function, the entire setting range can be selected while the device is idling. During welding, the main current can be corrected in steps of +/-20 A.



In the case of 4-step mode

Unit	% (of main current)
Setting range	0 - 100
Factory setting	50




DownSlope, 2-step mode




DownSlope, 4-step mode

Unit s
 Setting range 0.0 - 9.9
 Factory setting 1.0

IMPORTANT! The DownSlope is saved separately for 2-step and 4-step modes.




Final current, 2-step mode



Final current, 4-step mode

Unit % (of main current)
 Setting range 0 - 100
 Factory setting 30



only with MagicWave for the TIG AC welding process

Unit 1
 Setting range -5 - +5
 Factory setting 0

-5: highest fusing power, lowest cleaning action

+5: highest cleaning action, lowest fusing power




If cold wirefeeder option is available

Unit	m/min	ipm
Setting range	OFF / 0.1 - max.	OFF / 3.9 - max.
Factory setting	OFF	




Unit	mm	in.
Setting range	OFF - max.	OFF - max.
Factory setting	2.4	0.1


Welding parameters for rod electrodes



Starting current: starting current < main current ("SoftStart")




Starting current: starting current = main current




Starting current: starting current > main current ("Hot-Start")


Unit	% (of main current)
Setting range	0 - 200
Factory setting	150



Main current: starting current < main current ("SoftStart")




Main current: starting current = main current



Main current: starting current > main current ("HotStart")

Unit	A	
Setting range	MW 2200 Comfort 10 - 180	TT 2200 Comfort 10 - 180
	MW 2500 Comfort 10 - 250	TT 2500 Comfort 10 - 250
	MW 3000 Comfort 10 - 300	TT 3000 Comfort 10 - 300
	MW 4000 Comfort 10 - 400	TT 4000 Comfort 10 - 400
	MW 5000 Comfort 10 - 500	TT 5000 Comfort 10 - 500
Factory setting	-	




To obtain optimum welding results, it will sometimes be necessary to adjust the arc-force dynamic.

Unit	% (of main current)
Setting range	0 - 100
Factory setting	20
0	soft, low-spatter arc
100	harder, more stable arc

Functional principle:

at the instant of droplet transfer or in the event of a short circuit, there is a momentary rise in amperage. In order to obtain a stable arc, the welding current is temporarily increased. If the rod electrode threatens to sink into the weld pool, this measure prevents the weld pool solidifying, as well as preventing more prolonged short circuiting of the arc. This largely prevents the rod electrode from sticking.



only with MagicWave for the manual metal arc AC welding process

Unit	1
Setting range	-5 - +5
Factory setting	0

-5: highest fusing power, lowest cleaning action

+5: highest cleaning action, lowest fusing power

Preparation

- 1 Set up and install the power source in accordance with the welding job
- 2 Plug in the mains plug

CAUTION!

Risk of injury and damage from electric shock.

As soon as the mains switch is in the "I" position, the tungsten electrode of the welding torch is live.

- Ensure that the tungsten electrode does not touch any persons or electrically conductive or earthed parts (e.g. housing, etc.).

- 3 Move the mains switch to the "I" position

The starting sequence with the Fronius logo, current firmware version and Fronius internet address is displayed for approx. 1 second:



Welding job




- 1 Press Menu key
The relevant main menu appears, e.g.:




- 2 Use the adjusting dial to select "job" (turn the adjusting dial)



- 3 Press the adjusting dial
The menu items for the job will now appear:




- 4 Use the adjusting dial to select 'Retrieve' (turn the adjusting dial)






- 5 Press the adjusting dial


The display now shows the last job that was selected:



A free memory location is indicated as follows:



- 6 Use the adjusting dial to select the desired job (turn the adjusting dial)




- 7 To change welding parameters according to the job correction stored in the job:




- Use left and right arrow keys to select welding parameters



- Press the adjusting dial
The value of the selected welding parameter is displayed in a box:




- Use the adjusting dial to set the required value (turn the adjusting dial)





- Press the adjusting dial
The adjusted value of the selected welding parameter is applied




- 8 Start welding

Finishing the welding job

- 1 Finish welding




- 2 Press Menu key
The main menu for the welding job appears:




- 3 Use the adjusting dial to select "job" (turn the adjusting dial)



- 4 Press the adjusting dial
The menu items for an active job will now appear:




- 5 Use the adjusting dial to select "Finish" (turn the adjusting dial)





6 Press the adjusting dial

The welding parameters are shown for the most recently selected method, e.g.:



Starting current 2-step mode


Saving settings as a job

General


In the individual welding processes, settings and welding parameters can be stored in 100 jobs (job numbers 0 to 99).

Preparation

- 1 Select the mode to be saved using the Mode button:




The relevant image for the welding parameters is displayed, e.g.:



TIG welding parameters for 2-step mode (main current welding parameter selected)

- 2 Only for MagicWave: press the Process button to select the required welding process



- 3 Use the right arrow key to select the individual welding parameters



- 4 Change the welding parameter value by turning the adjusting dial



- 5 Press the Menu key in order to set other welding parameters in the set-up menu

The relevant menu is displayed, e.g.:



- 6 Use the adjusting dial to select the desired set-up menu



- 7 Open the selected set-up menu by pressing the adjusting dial



- 8 Use the adjusting dial to select a welding parameter



- 9 To change a welding parameter press the adjusting dial



10 Change the welding parameter value using the adjusting dial



11 Press the adjusting dial



12 Press Menu key

The latest menu appears, e.g.:



Saving settings as a job

NOTE!

When settings are saved as a job, all the settings are stored in the welding parameters as well as in the relevant set-up menus in a job.

When creating jobs you MUST therefore also take into account the welding parameters in the set-up menus.




1 Select the job from the relevant set-up menu by turning the 'Job' adjusting dial



2 Press the adjusting dial

The menu items for the job will now appear:



3 Use the adjusting dial to select "Save" (turn the adjusting dial)



- 4** Press the adjusting dial
The first "Save job" screen will appear:



- 5** Turn the adjusting dial to select the job number under which the settings are to be stored



- 6** Press the adjusting dial
- If there is memory available, then the settings will be stored under the selected job number.
 - If all the memory is occupied, then a warning prompt will appear.

Free memory:

The second "Save job" screen appears briefly:

The "Name job" screen appears:



- 7** Name job:
- Turn the adjusting dial to select the desired letters / numbers:



- Then press the adjusting dial in order to enter these letters / numbers:

Name job	
Job 01	S
A B C D E F G H I J K L M	
N O P Q R S T U V W X Y Z	
Cancel	OK



- In order to delete letters / numbers, turn the adjusting dial and select 'Del':

Name job	
Job 01	Side_up_02
/ \ _ - + * ~ # % & . , 0	
1 2 3 4 5 6 7 8 9 Del	
Cancel	OK



- Press the adjusting dial to delete the last character:

Name job	
Job 01	Side_up_0
/ \ _ - + * ~ # % & . , 0	
1 2 3 4 5 6 7 8 9 Del	
Cancel	OK



- Press the button on the right (OK) in order to accept the name

Name job	
Job 01	Side_up_01
/ \ _ - + * ~ # % & . , 0	
1 2 3 4 5 6 7 8 9 Del	
Cancel	OK

The settings will be stored and the third 'Save job' screen will appear:

Save job	
Job no 001 is saved	
OK	



- 8 Press the button on the right (OK)
The job numbers overview appears:

Allocated memory:

A warning prompt will appear:



- 7 Press the button on the left or right:

- Left button (No): Do not overwrite job, return to job numbers overview



- Right button (Yes): Store settings under the chosen job number:

The "Name job" screen appears:



- If necessary, delete the existing job name: Turn the adjusting dial and select 'Del'



- Press the adjusting dial to delete the last character:

-
- Name job
 Job 01
 A B C D E F G H I J K L M
 N O P Q R **S** T U V W X Y Z
 Cancel OK



-
- Name job**
- Job 01 S
- A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z
- Cancel OK




-
- Name job
 Job 01 Side_up_01
 / \ _ - + * ~ # % & . , 0
 1 2 3 4 5 6 7 8 9 Del
 Cancel OK

Save job

Job no 001 is saved

OK



- 

Finish saving job




1 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The menu items for the job will now appear:




2 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The current set-up menu is displayed:






3 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

The current welding parameters are displayed e.g.:



TIG welding parameters for 2-step mode (main current welding parameter selected)

Setup settings

The Setup menu

General

The set-up menu provides easy access to the knowledge base in the power source and to additional functions. The set-up menu can be used to make simple adjustments of the welding parameters to suit the various job settings.

- The set-up menu contains all the set-up parameters that have an immediate effect on the welding process.
- The 2nd level of the set-up menu contains all the set-up parameters needed for making the preliminary settings on the welding device.

The welding parameters are arranged in logical groups.

Overview

The Setup menu is composed of the following sections:


- TIG-setup
- TIG setup 2nd
- AC-setup
- AC setup 2nd
- Gas-setup
- Coldwire-setup
- Push-pull calibration
- Rod elect. Setup (rod electrode setup)
- Rod elect. Setup 2nd (rod electrode setup 2nd)
- AC-setup (for rod electrodes)
- Job
- Basic setting
- Info
- Lock keys
- Factory - for resetting the welding system
- L/R alignment

TIG setup


Opening the TIG setup



- 1 Press the Mode button to select 2-step mode or 4-step mode
The image for the TIG welding parameter is shown on the display:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode




- 2 Press Menu key
The main menu appears:



- 3 Use the adjusting dial to select "TIG setup" (turn the adjusting dial)



- 4 Press the adjusting dial
The TIG setup parameters are shown:



The power source is now in the TIG setup.

Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:

TIG-setup	
Spotwelddtime	Off
Tack. fctn	Off
Puls freq.	Off
Duty cycle	50 %



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:

TIG-setup	
Spotwelddtime	Off
Tack. fctn	Off
Puls freq.	Off
Duty cycle	50 %



- 3 Change the welding parameter value by turning the adjusting dial:

TIG-setup	
Spotwelddtime	Off
Tack. fctn	2.2 s
Puls freq.	Off
Duty cycle	50 %



- 4 To apply the welding parameter value press the adjusting dial

TIG-setup	
Spotwelddtime	Off
Tack. fctn	2.2 s
Puls freq.	Off
Duty cycle	50 %

Exiting TIG setup



1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

TIG-setup	
Spotweldtime	Off
Tack. fctn	2.2 s
Puls freq.	Off
Duty cycle	50 %



- Press the adjusting dial

The main menu appears:

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	



2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	




- Press the adjusting dial

The image for the TIG welding parameter is shown:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode


Welding parameters in the TIG set-up

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wire-feed unit, welding program, etc.

Spot welding time

Unit	s
Setting range	OFF / 0.05 - 25.0
Factory setting	OFF

If a value has been set for the spot welding time, "2-step mode" will work in the same way as spot welding mode.

 The spot welding indicator remains lit on the control panel as long as a value has been specified for the spot welding time.

Tacking function


for the TIG DC welding process: Duration of the pulsed welding current at the start of tacking

Unit	s
Setting range	OFF / 0.1 - 9.9 / ON
Factory setting	OFF

ON The pulsed welding current remains in effect until the end of the tacking operation

0.1 - 9.9 s The set time begins with the upslope phase. After the end of the pre-set time period, welding continues with a constant welding current; any pulsing parameters that have been set are available.

OFF The tacking function is deactivated

 The tacking indicator remains lit on the control panel as long as a value has been specified for the tacking time.


Pulse frequency

Unit	Hz / kHz
Setting range	OFF / 0.20 Hz - 2.00 kHz
Factory setting	OFF

The selected pulse frequency is also used for the reduced current I_2 .

IMPORTANT! If the pulse frequency is set to "OFF":

- then the welding parameters Duty Cycle, Ground Current and Wirefeed spd2 (from cold wire setup) are not available
- the wire feed speed set on the control panel is used for constant wirefeed at a constant welding current.

 The pulse indicator remains lit on the control panel as long as a value has been specified for the pulse frequency.

Setting the pulse frequency:

0.2 Hz to 5 Hz	Thermal pulsing (out-of-position welding, automated welding)
1 kHz to 2 kHz	Arc-stabilising pulsing (stabilising the arc at a low welding current)

Duty Cycle

The ratio of pulse duration to base current duration when a pulse frequency has been set

Unit	%
Setting range	10 - 90
Factory setting	50

Ground current

Unit	% (of main current I_1)
Setting range	0 - 100
Factory setting	50

Starting current time

Unit	s
Setting range	OFF / 0.01 - 9.9
Factory setting	OFF

The starting current time t_S specifies the duration of the starting-current phase I_S .


IMPORTANT! The starting current time only applies in 2-step mode. In 4-step mode, the duration of the starting-current phase I_S is controlled using the torch trigger

Final current time

Unit	s
Setting range	OFF / 0.01 - 9.9
Factory setting	OFF

The final current time t_E specifies the duration of the final current phase I_E .

IMPORTANT! The final current time only applies in 2-step mode. In 4-step mode, the duration of the final current phase I_E is controlled with the torch trigger (see: "TIG operating modes").



2-step mode: Starting and final current time

Legend:

GPr	Gas pre-flow time
I_S	Starting current
t_S	Starting current time
t_{up}	UpSlope

I_1	Main current
t_{down}	Downslope
I_E	Final current
t_E	Final current time

TIG-Setup 2nd

Second level of the TIG setup

TIG setup 2nd

Opening the TIG setup 2nd



- 1 Opening the TIG setup
- 2 Select the 'TIG setup 2nd' parameter

TIG-setup	
Base crnt	50 %
Start crnt time	Off
End crnt time	Off
TIG-setup 2nd	



- 3 Press the adjusting dial
The TIG setup 2nd parameters are shown:

TIG-setup 2nd	
Spec. 4-step	Off
Cool. unit ctrl	Aut
Cunit wtchdog	10 s
HF ignition	0.01 s

The power source is now in TIG setup 2nd

Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:

TIG-setup 2nd	
Spec. 4-step	Off
Cool. unit ctrl	Aut
Cunit wtchdog	10 s
HF ignition	0.01 s



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:

TIG-setup 2nd	
Spec. 4-step	Off
Cool. unit ctrl	Aut
Cunit wtchdog	10 s
HF ignition	0.01 s



- 3 Change the welding parameter value by turning the adjusting dial:

TIG-setup 2nd	
Spec. 4-step	Off
Cool. unit ctrl	Off
Cunit wtchdog	10 s
HF ignition	0.01 s



- 4 To apply the welding parameter value press the adjusting dial

TIG-setup 2nd	
Spec. 4-step	Off
Cool. unit ctrl	Off
Cunit wtchdog	10 s
HF ignition	0.01 s

Exiting TIG setup 2nd



- 1 Press Menu key
or



- Select the arrow symbol by turning the adjusting dial

TIG-setup 2nd	
Spec. 4-step	Off
Cool. unit ctrl	Off
Cunit wtchdog	10 s
HF ignition	0.01 s



- Press the adjusting dial

The TIG setup parameters are shown:

TIG-setup	
Base crnt	50 %
Start crnt time	Off
End crnt time	Off
TIG-setup 2nd	



2 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

TIG-setup	
Spotwelddtime	Off
Tack. fctn	2.2 s
Puls freq.	Off
Duty cycle	50 %



- Press the adjusting dial

The main menu appears:

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	



3 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	




- Press the adjusting dial

The image for the TIG welding parameter is shown:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode

Welding parameters in the TIG set-up 2nd

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wirefeeder, welding program, etc.

Spec. 4-step

Special 4-step mode

Unit	-
Setting range	OFF / 1 - 3
Factory setting	OFF
1	Variant 1
2	Variant 2
3	Variant 3

Cool. unit ctrl

Cooling unit control (option)

Unit	-
Setting range	Aut / ON / OFF
Factory setting	Aut
Aut	Cooling unit is switched off 2 minutes after the end of welding
ON	Cooling unit is ON all the time
OFF	Cooling unit is OFF all the time

IMPORTANT! If the cooling unit is provided with the optional "thermostat", the coolant return temperature is checked continuously. If the return temperature is less than 50 °C, the cooling unit is switched off automatically.

Cunit wtchdog

Cooling unit monitoring

Time from when the flow sensor is triggered until the "no | H2O" service code is output. For example, if there are air bubbles in the cooling system, the cooling unit will not cut out until the end of this preset time.

Unit	s
Setting range	5 - 25
Factory setting	10

IMPORTANT! Every time the power source is switched on, the cooling unit carries out a test run for 180 seconds.

HF ignition

High frequency ignition: Time interval between the HF pulses

Unit	s
Setting range	0.01 - 0.4 / OFF / EHF (start with external arc starters, e.g. plasma welding)
Factory setting	0.01

NOTE!

If there are problems with sensitive equipment in the immediate vicinity, increase the HF ignition parameter to a maximum of 0.4 s.

HF The special HF ignition indicator lights up on the control panel provided that a value has been specified for the HF ignition parameter.

If the "HF ignition" setup parameter is set to "OFF", no high frequency ignition takes place at the start of welding. In this case, welding starts with touchdown ignition.



CAUTION!

Risk of injury due to shock caused by electric shock

Although Fronius devices comply with all relevant standards, high-frequency ignition can transmit a harmless but noticeable electric shock under certain circumstances.

- ▶ Use prescribed protective clothing, especially gloves!
- ▶ Only use suitable, completely intact and undamaged TIG hosepacks!
- ▶ Do not work in damp or wet environments!
- ▶ Take special care when working on scaffolding, work platforms, in forced positions (out-of-position welding), in tight, difficult to access or exposed areas!

rPI ignition

Reversed polarity ignition

Unit	-
Setting range	ON / OFF
Factory setting	OFF

IMPORTANT! The rPI ignition function

- is only available on the MagicWave power source
- is not recommended for welding light-gauge sheets

L/R alignment

L (inductivity) - welding circuit inductivity (in microhenry)
R (resistance) - welding circuit resistance (in mOhm)

See the "L/R alignment" section for further details.

Ignition time-out

Time until safety cut-out is triggered after abortive ignition attempt

Unit	s
Setting range	0.1 - 9.9
Factory setting	5

IMPORTANT! "Ignition Time-Out" is a safety function so it cannot be deactivated. A description of the ignition time out function can be found in the Chapter "TIG welding".

Arc break

Arc break watchdog

Time until safety cut-out following an arc break

Unit	s
Setting range	0.1 - 9.9
Factory setting	2

IMPORTANT! The arc break watchdog is a safety function and cannot be deactivated. A description of the arc break watchdog function can be found in the section "TIG welding".

Ext. parameter

External parameter

a user-defined welding parameter for the JobMaster TIG welding torch or robot interface (both optional).

A freely selectable welding parameter is available both on the JobMaster TIG welding torch and for the robot interface. If "Ext. parameter" has been selected, you can use the adjusting dial to choose between the following possibilities for this freely definable welding parameter:

OFF	No freely defined welding parameter has been assigned (factory setting)	I-E	Final current
ELd	Electrode diameter	ACF	AC frequency
bAL	Balance	F-P	Pulse frequency
SPT	Spot welding time	dcY	Duty cycle
I-S	Starting current	I-G	Base current
UPS	UpSlope	tAC	Tacking function: Duration of the tacking operation
I-2	Reduced current	Fd.1	Wire speed 1 (cold wirefeeder option)
dsl	DownSlope		

The number of user-defined welding parameters depends on the configuration and the mode that has been selected.

Special 2-step

Special 2-step mode for HF ignition after touching the workpiece

Unit	-
Setting range	OFF / 1
Factory setting	OFF

Ignition sequence, when the STS parameter is set to 1:

- Touch the workpiece with the tungsten electrode
- The short circuit detection on the power source is triggered
- Lift the tungsten electrode off
- After 300 ms the gas pre-flow time begins
- HF ignition is initiated
- End of welding due to arc break

Ign. delay

Ignition delay

Delayed ignition with immediate high frequency start

Unit	s
Setting range	OFF / 0.1 - 1
Factory setting	OFF

If a time value is set for the welding parameter "Ign. delay", the welding arc ignition is delayed by this time value: Press the torch trigger - high frequency is activated for the specified duration - the welding arc is ignited

AC setup


General

This setup is only available with MagicWave power sources.


Open the AC set-up



- 1 Press the Mode button to select 2-step mode or 4-step mode
The image for the TIG welding parameter is shown on the display:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode



- 2 Press Menu key
The main menu appears:






- 3 Use the adjusting dial to select "AC setup" (turn the adjusting dial)



- 4 Press the adjusting dial
The AC setup parameters are shown:




The power source is now in AC setup.


Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:




- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:






- 3 Change the welding parameter value by turning the adjusting dial:



- 4 To apply the welding parameter value press the adjusting dial



Exiting AC setup




- 1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The main menu appears:



- 2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial






- Press the adjusting dial

The image for the TIG welding parameter is shown:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode

Welding parameters in AC setup

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wire-feed unit, welding program, etc.

AC frequency

Unit	Hz
Setting range	Syn / 40 - 250
Factory setting	60
Syn	for mains synchronisation of two power sources for simultaneous AC welding.

IMPORTANT! If using the "Syn" setting, remember to check the "Phase sync." parameter in AC setup 2nd.


Low frequency	soft, distant arc with shallow heat input
High frequency	focused arc with deep heat input

AC current offset

Unit	%
Setting range	-70 to +70
Factory setting	0
+70	distant arc with shallow heat input
-70	narrow arc, deep heat input, faster welding speed

AC setup 2nd

second level of the AC setup



Effect of the AC parameters on the waveshape

- (1) Balance
- (2) AC frequency
- (3) AC current offset
- *) Factory setting: 20% shift to the negative

AC setup 2nd

General

This setup is only available with MagicWave power sources.

Opening the AC setup 2nd



- 1 Open the AC setup
- 2 Select the 'AC setup 2nd' parameter

AC-setup	
AC frequency	110 Hz
AC-currentoffset	0 %
AC setup 2nd	



- 3 Press the adjusting dial
The AC setup 2nd parameters are shown:

AC setup 2nd	
Pos half-wave	Sin
Neg half-wave	rec
Phase sync.	0

The power source is now in AC setup 2nd.

Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:

AC setup 2nd	
Pos half-wave	Sin
Neg half-wave	rec
Phase sync.	0



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:

AC setup 2nd	
Pos half-wave	Sin
Neg half-wave	rec
Phase sync.	0



- 3 Change the welding parameter value by turning the adjusting dial:

AC setup 2nd	
Pos half-wave	Sin
Neg half-wave	rec
Phase sync.	2



- 4 To apply the welding parameter value press the adjusting dial

AC setup 2nd	
Pos half-wave	Sin
Neg half-wave	rec
Phase sync.	2

Exiting AC setup 2nd



- 1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

AC setup 2nd	
Pos half-wave	Sin
Neg half-wave	rec
Phase sync.	2



- Press the adjusting dial

The AC setup parameters are shown:

AC-setup	
AC frequency	110 Hz
AC-currentoffset	0 %
AC setup 2nd	




2 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The main menu appears:



3 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial




- Press the adjusting dial

The image for the TIG welding parameter is shown:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode

Welding parameters in AC setup 2nd

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wire-feed unit, welding program, etc.

Pos half-wave

positive half-wave

Unit	-
Setting range	Tri / Sin / Rec / Off
Factory setting	Sin
Tri	Triangular waveform
Sin	Sine ... sinusoidal waveform (standard setting for a low-noise, stable arc)
Rec	Rectangular waveform with decreased edge steepness, for reducing noise levels compared to those that occur with the 100% rectangular waveform
Off	100% rectangular waveform (stable but loud arc)

Neg. half-wave

Negative half-wave

Unit	-
Setting range	Tri / Sin / Rec / Off
Factory setting	OFF
Tri	Triangular waveform
Sin	Sine ... sinusoidal waveform (standard setting for a low-noise, stable arc)
Rec	Rectangular waveform with decreased edge steepness, for reducing noise levels compared to those that occur with the 100% rectangular waveform
Off	100% rectangular waveform (stable but loud arc)

Phase sync.

Phase synchronisation of mains connection of two power sources for simultaneous AC welding.

Unit	-
Setting range	0 - 5
Factory setting	0

IMPORTANT! Before phase synchronisation, the "AC frequency" welding parameter must be set to "Syn" in the AC setup.

Phase adjustment takes place as follows:

- Prepare a test workpiece for simultaneous AC welding.
- Adjust the phase synchronisation value on a power source to between 0 and 5 until the best welding result is achieved.

Gas setup


General

The gas setup offers easy access to the protective gas shield settings.


Opening the gas setup



- 1 Press the Mode button to select 2-step mode or 4-step mode
The image for the TIG welding parameter is shown on the display:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode



- 2 Press Menu key
The main menu appears:






- 3 Use the adjusting dial to select "gas setup" (turn the adjusting dial)



- 4 Press the adjusting dial
The gas setup parameters are shown:




The power source is now in gas setup.


Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:





- 3 Change the welding parameter value by turning the adjusting dial:

Gas-setup	
Pre-flow	0.4 s
Post-flow lmin	7.0 s
Post-flow lmax	Aut
Gas qntity	15.0 l/min



- 4 To apply the welding parameter value press the adjusting dial

Gas-setup	
Pre-flow	0.4 s
Post-flow lmin	7.0 s
Post-flow lmax	Aut
Gas qntity	15.0 l/min

Exiting gas setup



- 1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

Gas-setup	
Pre-flow	0.4 s
Post-flow lmin	7.0 s
Post-flow lmax	Aut
Gas qntity	15.0 l/min



- Press the adjusting dial

The main menu appears:

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	



- 2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	




- Press the adjusting dial

The image for the TIG welding parameter is shown:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode

Gas setup parameters

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wire-feed unit, welding program, etc.

Pre-flow

Gas pre-flow time

Unit	s
Setting range	0,0 - 9,9
Factory setting	0,4

Post-flow I_{min}

Post-flow at I_{min}

Gas post-flow time at minimum welding current (minimum gas post-flow time)

Unit	s
Setting range	0 - 25
Factory setting	5

Post-flow I_{max}

Post-flow at I_{max}

Increase in gas post-flow time at maximum welding current


Unit	s
Setting range	0 - 40/Aut
Factory setting	Aut

The value set for "post-flow I_{max}" only applies if the maximum welding current actually has been set. The actual value is derived from the present welding current. With a medium welding current, for example, the actual value will be one-half of the value set for "post-flow I_{max}".

IMPORTANT! The values set for the 'post-flow I_{min}' and 'post-flow I_{max}' welding parameters are added together. For example, if both welding parameters are at maximum (25 s / 40 s), the gas post-flow will last:

- 25 s at minimum welding current
- 65 s at maximum welding current
- 37.5 s if the welding current is exactly half the maximum, etc.

If Aut is selected, the gas post-flow time is calculated automatically. This takes the selected process (AC or DC welding) into account.



Legend:

(1).... Gas post-flow time at any given moment

(2).... Welding current at any given moment

G-H.... Post-flow I_{max}

G-L Post-flow I_{min}

Gas post-flow time as a function of the welding current

Gas qntity

Command value for protective gas shield flow (only with the "digital gas control" option)

Unit	l/min	cfh
Setting range	OFF / 5.0 - max.	OFF / 10.71 - max.
Factory setting	15	32.14

IMPORTANT! Please refer to "Digital Gas Control" operating instructions for more detailed explanations of the "gas flow rate" welding parameter.

Gas correction

(only with the "Digital Gas Control" option)

Unit	-
Setting range	AUT / 1.0 - 10.0
Factory setting	AUT

IMPORTANT! Please refer to "Digital Gas Control" operating instructions for more detailed explanations of the "gas correction" welding parameter.

Gas flushing

Purging of protective gas shield

Unit	min
Setting range	OFF / 0.1 - 10.0
Factory setting	OFF

Purging of the protective gas shield begins as soon as "gas flushing" is allocated a value. For safety reasons, purging of the shielding gas cannot be restarted until a new gas flushing value is entered.

IMPORTANT! Purging of the protective gas shield is necessary if condensation forms when the device is left unused in a cold environment for a prolonged period. Long hose-packs are most affected.

Cold wire setup


General

The cold wire setup is only available if a cold wire feeder is connected to the power source.


Opening the AC setup



- 1 Press the Mode button to select 2-step mode or 4-step mode
The image for the TIG welding parameter is shown on the display:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode



- 2 Press Menu key
The main menu appears:






- 3 Use the adjusting dial to select "cold wire setup" (turn the adjusting dial)



- 4 Press the adjusting dial
The cold wire setup welding parameters are shown:




The power source is now in the cold wire setup.


Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:





- 3 Change the welding parameter value by turning the adjusting dial:

Cold wire-setup	
Wirefeed spd2	50 %
Start-delay	1.2 s
End-delay	Off
Feedingin	1.00 m/min



- 4 To apply the welding parameter value press the adjusting dial

Cold wire-setup	
Wirefeed spd2	50 %
Start-delay	1.2 s
End-delay	Off
Feedingin	1.00 m/min

Exiting the cold wire setup



- 1 Press Menu key
or



- Select the arrow symbol by turning the adjusting dial

Cold wire-setup	
Wirefeed spd2	50 %
Start-delay	1.2 s
End-delay	Off
Feedingin	1.00 m/min



- Press the adjusting dial

The main menu appears:

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	



- 2 Press Menu key
or




- Select the arrow symbol by turning the adjusting dial

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	




- Press the adjusting dial

The image for the TIG welding parameter is shown:



TIG welding parameters for 2-step mode



TIG welding parameters for 4-step mode

Welding parameters in the cold wire setup

"Minimum" and "maximum" are used for setting ranges that differ according to power source, cold wire-feed unit, welding program, etc.

Wirefeed spd2

Wire feed speed 2

Unit	% (of the wire feed speed)
Setting range	0 - 100
Factory setting	50

If a value is set for both 'wire feed speed 2' and 'pulse frequency', then the wire feed speed alternates between the following values in sync with the pulse frequency of the welding current:

- Wire feed speed from the TIG welding parameters
- Wire feed speed 2

Start-delay

Delay in the start of wirefeeding from beginning of the main current phase

Unit	s
Setting range	OFF / 0.1 - 9.9
Factory setting	OFF

End-delay

Delay in the start of wirefeeding from end of the main current phase

Unit	s
Setting range	OFF / 0.1 - 9.9
Factory setting	OFF

Wire threading

Wire threading speed

Unit	m/min	ipm.
Setting range	1,0 - max.	39.37 - max.
Factory setting	5	197

Wire wdraw

Unit	mm	in.
Setting range	OFF / 1 - 50	OFF / 0.04 - 1.97
Factory setting	OFF	OFF

IMPORTANT! Wire withdrawal prevents the welding wire from burning at the end. Before the welding current is switched off, the wire is withdrawn to the set value. A prerequisite for this function is that the arc has ignited.

Push-pull

Selecting and calibrating the push-pull unit

Unit	-	
Setting range	00 - KD7000/VR1530KD22m 01 - KD7000/VR1530KD30m 02 - RobactaKD-Drive 10m 03 - RobactaKD-Drive 220m 15 - KD7000/VR1530KD10m	18 - RobactaKD-Drive 5m 19 - KD4010 10m 21 - BinzelTorchDr.IWG 8m 25 - KD7000-VR1530KD10m
Factory setting	0	

Calibrating push-pull unit

General


The push-pull unit must be calibrated before it is started up for the first time and whenever the wire feed software is updated. If the push-pull unit is not calibrated, standard welding parameters will be used - which may lead to an unsatisfactory welding result.

Calibrating the push-pull unit


For an overview of the service codes used during calibration of the push-pull unit, please refer to "Service codes for push-pull calibration".



- 1 In cold wire setup select the "PushPull" parameter




- 2 Press the adjusting dial
The first push-pull calibration screen is shown:




On the following push-pull calibration screens pressing the left button takes you back to the previous screen.



- 3 Press the right arrow key
The second push-pull calibration screen is shown:




- 4 Use the adjusting dial to select the corresponding push-pull unit:





- 5 Press the right arrow key
The third push-pull calibration screen is shown:



- 6 Follow the instructions shown




CAUTION!

Risk of injury from rotating cogs and drive parts.

- Keep hands away from rotating cogs and the wire drive parts.
-



- 7 Press the right arrow key
The fourth push-pull calibration screen is shown:



- 8 Follow the instructions shown



CAUTION!


Risk of injury from welding wire emerging and from rotating cogs and drive parts.

- Keep the welding torch away from your face and body.
 - Keep hands away from rotating cogs and the wire drive parts.
-




9 Press the right arrow key

A confirmation appears once the push-pull unit has been calibrated:



10 Press the right arrow key

The cold wire setup welding parameters are shown:



General

No.	Push-pull unit	Wire feed speed
00	Fronius KD 7000 Fronius VR 1530 KD	22 m/min or 866 ipm
01	Fronius KD 7000 Fronius VR 1530 KD	30 m/min or 1181 ipm
02	Fronius Robacta KD Drive Fronius Robacta Plasma KD Drive Fronius Robacta Laser KD Drive	10 m/min or 394 ipm
03	Fronius Robacta KD Drive Fronius Robacta Plasma KD Drive Fronius Robacta Laser KD Drive	22 m/min or 866 ipm
15	Fronius KD 7000 Fronius VR 1530 KD	10 m/min or 394 ipm
18	Fronius Robacta KD Drive Fronius Robacta Plasma KD Drive Fronius Robacta Laser KD Drive	5 m/min or 197 ipm
19	Fronius KD 4010	10 m/min or 394 ipm
21	Binzel Torch Drive IWG	8 m/min or 315 ipm
25	Fronius KD 7000 Fronius VR 1530 KD	10 m/min or 394 ipm

Service codes during calibration of the push-pull unit

The following abbreviations are used for the service codes shown during calibration of the push-pull unit:







KD = Cold wire-feed unit

PPU = Push-pull unit







vDmin = minimum wire feed speed





vDmax = maximum wire feed speed

Service codes when the drive units are disengaged (open-circuit calibration)

<div> <div>Eto</div> <div>  Calibration lasts more than 20 s </div> <div>OK ▶</div> </div>	<p>Cause: Incorrect measurement during push-pull calibration</p> <p>Remedy: Repeat push-pull calibration</p>
<div> <div>St1 - E1</div> <div>  No speed value from wirefeeder motor vD mins </div> <div>OK ▶</div> </div>	<p>St1 - E1, St1 - E3</p> <p>Cause: At minimum wire feed speed, the wire-feed unit motor does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>
<div> <div>St1 - E2</div> <div>  No speed value from wirefeeder motor vD max </div> <div>OK ▶</div> </div>	<p>St1 E 2, St1 - E5</p> <p>Cause: At maximum wire feed speed, the wire-feed motor does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>
<div> <div>St1 - E4</div> <div>  No speed value from PPU motor vD min </div> <div>OK ▶</div> </div>	<p>Cause: At minimum wire feed speed, the motor of the push-pull unit does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>
<div> <div>St1 - E6</div> <div>  No speed value from PPU motor vD max </div> <div>OK ▶</div> </div>	<p>Cause: At maximum wire feed speed, the motor of the push-pull unit does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>
<div> <div>St1 - E16</div> <div>  Emergency stop from torch trigger or feeder button </div> <div>OK ▶</div> </div>	<p>Cause: Push-pull calibration was interrupted: Quick-stop was activated by pressing the torch trigger.</p> <p>Remedy: Repeat push-pull calibration</p>

Service codes when the drive units are engaged (engaged calibration)

<div> <div>St2 - E7</div> <div>  No-load calibration not carried out </div> <div>OK ▶</div> </div>	<p>Cause: "Push-pull calibration - open-circuit" has not been carried out</p> <p>Remedy: Carry out "push-pull calibration - open-circuit"</p>
<div> <div>St2 - E8</div> <div>  No speed value from wirefeeder motor vD min </div> <div>OK ▶</div> </div>	<p>Cause: At minimum wire feed speed, the wire-feed unit motor does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>
<div> <div>St2 - E9</div> <div>  No speed value from PPU motor vD min </div> <div>OK ▶</div> </div>	<p>Cause: At minimum wire feed speed, the motor of the push-pull unit does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>
<div> <div>St2 - E10</div> <div>  Wirefeeder motor current out of tolerance vD min </div> <div>OK ▶</div> </div>	<p>Cause: At minimum wire feed speed, the motor current of the wire-feed unit motor is outside the permitted range. Possible reasons are disengaged wire-feed unit motors or wire feed problems.</p>
<p>Remedy: Engage the drive units of both wirefeeder motors, arrange the hosepack in as straight a line as possible; check the inner liner for kinks or soiling; check the contact pressure on the 2-roller or 4-roller drive of the push-pull unit. Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>	
<div> <div>St2 - E11</div> <div>  PPU motor current out of tolerance vD min </div> <div>OK ▶</div> </div>	<p>Cause: At minimum wire feed speed, the motor current of the push-pull unit is outside the permitted range. Possible reasons are disengaged wire-feed unit motors or wire feed problems.</p>
<p>Remedy: Engage the drive units of both wirefeeder motors, arrange the hosepack in as straight a line as possible; check the inner liner for kinks or soiling; check the contact pressure on the 2-roller or 4-roller drive of the push-pull unit. Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>	
<div> <div>St2 - E12</div> <div>  No speed value from wirefeeder motor vD max </div> <div>OK ▶</div> </div>	<p>Cause: At maximum wire feed speed, the wire-feed motor does not deliver any actual rotational speed value.</p> <p>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</p>

<div> <div>St2 - E13</div> <div>  No speed value from PPU motor vD max </div> <div>OK ▶</div> </div>	<div> <div>Cause: At maximum wire feed speed, the motor of the push-pull unit does not deliver any actual rotational speed value.</div> <div>Remedy: Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service, faulty actual value pick-up St2 E 14</div> </div>
<div> <div>Cause: At maximum wire feed speed, the motor current of the wire-feed unit motor is outside the permitted range. Possible reasons are disengaged wire-feed unit motors or wire feed problems.</div> <div>Remedy: Engage the drive units of both wirefeeder motors, arrange the hosepack in as straight a line as possible; check the inner liner for kinks or soiling; check the contact pressure on the 2-roller or 4-roller drive of the push-pull unit. Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</div> </div>	
<div> <div>St2 - E14</div> <div>  Wirefeeder motor current out of tolerance vD max </div> <div>OK ▶</div> </div>	<div> <div>Cause: At maximum wire feed speed, the motor current of the wire-feed unit motor is outside the permitted range. Possible reasons are disengaged wire-feed unit motors or wire feed problems.</div> </div>
<div> <div>Remedy: Engage the drive units of both wire-feed unit motors, arrange the hosepack in as straight a line as possible; check the inner liner for kinks or soiling; check the contact pressure on the 2-roller or 4-roller drive of the push-pull unit. Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</div> </div>	
<div> <div>St2 - E15</div> <div>  PPU motor current out of tolerance vD max </div> <div>OK ▶</div> </div>	<div> <div>Cause: At maximum wire feed speed, the motor current of the push-pull unit is outside the permitted range. Possible reasons are disengaged wire-feed unit motors or wire feed problems.</div> </div>
<div> <div>Remedy: Engage the drive units of both wire-feed unit motors, arrange the hosepack in as straight a line as possible; check the inner liner for kinks or soiling; check the contact pressure on the 2-roller or 4-roller drive of the push-pull unit. Repeat the push-pull calibration. If the error message re-appears: Contact After-Sales Service.</div> </div>	
<div> <div>St2 - E16</div> <div>  Emergency stop from torch trigger or feeder button </div> <div>OK ▶</div> </div>	<div> <div>Cause: Push-pull calibration was interrupted: Quick-stop was activated by pressing the torch trigger.</div> <div>Remedy: Repeat push-pull calibration</div> </div>


Rod elec. setup (rod electrode setup)

Open the rod electrode setup



- 1 Press the Mode button to select the MMA welding mode

The image for the rod electrode welding parameter is shown on the display, e.g.:



- 2 Press Menu key

The main menu appears:




- 3 Use the adjusting dial to select "Rod elec. setup" (turn the adjusting dial)



- 4 Press the adjusting dial

The rod electrode setup parameters are shown:




The power source is now in the rod electrode setup.


Changing welding parameters




- 1 Select the desired welding parameter by turning the adjusting dial:




- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:



- 3 Change the welding parameter value by turning the adjusting dial:



- 4 To apply the welding parameter value press the adjusting dial



Exiting rod electrode-setup




1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The main menu appears:




2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The image for the rod electrode welding parameter is shown:



Rod electrode setup parameters:

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wire-feed unit, welding program, etc.

HotStart time

Unit	s
Setting range	0 - 2,0
Factory setting	0,5

To obtain optimum welding results, it will sometimes be necessary to adjust the hotstart function.

Advantages:

- Improved ignition, even when using electrodes with poor ignition properties
- Better fusion of the base material in the start-up phase, meaning fewer cold-shut defects
- Largely prevents slag inclusions

Rod elec. setup 2nd

Second level of the rod electrode setup

Rod elec. setup 2nd (rod electrode setup 2nd)

Opening the rod electrode setup 2nd



- 1 Open the rod electrode setup
- 2 Select the 'rod electrode setup 2nd' parameter

Rod elect. Setup	
Hotstart time	1.5 s
Rod elect. Setup 2nd	



- 3 Press the adjusting dial
The parameters for rod electrode setup 2nd are shown:

Rod elect. Setup 2nd	
Anti-stick	On
Char.	con
Break-voltage	Off
L/R align.	

The power source is now in rod electrode setup 2nd

Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:

Rod elect. Setup 2nd	
Anti-stick	On
Char.	con
Break-voltage	Off
L/R align.	



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:

Rod elect. Setup 2nd	
Anti-stick	On
Char.	con
Break-voltage	Off
L/R align.	



- 3 Change the welding parameter value by turning the adjusting dial:

Rod elect. Setup 2nd	
Anti-stick	On
Char.	5.1
Break-voltage	Off
L/R align.	



- 4 To apply the welding parameter value press the adjusting dial

Rod elect. Setup 2nd	
Anti-stick	On
Char.	5.1
Break-voltage	Off
L/R align.	

Exiting rod electrode setup 2nd



- 1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

Rod elect. Setup 2nd	
Anti-stick	On
Char.	5.1
Break-voltage	Off
L/R align.	



- Press the adjusting dial

The rod electrode setup parameters are shown:

Rod elect. Setup	
Hotstart time	0.0 s
Rod elect. Setup 2nd	




2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The main menu appears:




3 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The image for the TIG welding parameter is shown:



Rod electrode setup 2nd welding parameters

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wirefeeder, welding program, etc.

Anti-stick

Unit	-
Setting range	ON / OFF
Factory setting	ON


As the arc becomes shorter, the welding voltage may drop so far that the rod electrode will tend to stick. This may also cause the rod electrode to burn out.

Electrode burn-out is prevented by activating the anti-stick function. If the rod electrode begins to stick, the power source immediately switches the welding current off. After the rod electrode has been detached from the workpiece, the welding process can be continued without any problems.

Char.

To select characteristics

Unit	
Setting range	con or 0.1 - 20 or P
Factory setting	con



Characteristics that can be selected using the characteristic function

"con" parameter (constant welding current)

- If the "con" parameter is set, the welding current will be kept constant, irrespective of the welding voltage. This results in a vertical characteristic (4).
- The "con" parameter is especially suitable for rutile electrodes and basic electrodes, as well as for arc air gouging.
- For arc air gouging, set the arc-force dynamic to "100".

Parameter "0.1 - 20" (drooping characteristic with adjustable slope)

- Parameter "0.1 - 20" is used to set a drooping characteristic (5). The setting range extends from 0.1 A / V (very steep) to 20 A / V (very flat).
- Setting a flat characteristic (5) is only advisable for cellulose electrodes.

NOTE!


When setting a flat characteristic (5), set the arc-force dynamic to a higher value.

"P" parameter (constant welding power)

- If the "P" parameter is set, the welding power is kept constant, irrespective of the welding voltage and welding current. This results in a hyperbolic characteristic (6).
- The "P" parameter is particularly suitable for cellulose electrodes.

NOTE!

If there are problems with a rod electrode tending to "stick", set the arc-force dynamic to a higher value.



Settings example: $I_1 = 250$ A, arc-force dynamic = 50

The characteristics (4), (5) and (6) shown here apply when using a rod electrode whose characteristic corresponds to the load line (1) at a given arc length.

Depending on what welding current (I) has been set, the point of intersection (operating point) of characteristics (4), (5) and (6) will be displaced along the load line (1). The operating point provides information on the actual welding voltage and the actual welding current.

Where the welding current (I_1) is permanently set, the operating point may migrate along the characteristics (4), (5) and (6) depending on the welding voltage at that moment in time. The welding voltage U is dependent upon the arc length.

If the arc length changes, e.g. in accordance with the load line (2), the resulting operating point will be the point where the corresponding characteristic (4), (5) or (6) intersects with the load line (2).

Applies to characteristics (5) and (6): Depending upon the welding voltage (arc length), the welding current (I) will also become either smaller or larger, even though the value set for I₁ remains the same.

Break-voltage

Welding voltage limitation

Unit	-
Setting range	OFF or 5 - 90 V
Factory setting	OFF

The arc length depends on the welding voltage. To end the welding process, it is usually necessary to significantly lift the rod electrode away from the workpiece. With the "Uco" parameter, the welding voltage can be limited to a value that makes it possible to end the welding operation simply by slightly lifting the rod electrode.

NOTE!

If, during welding, you often find that the welding operation is ended unintentionally, increase the value of the Uco parameter.

L/R alignment

L (inductivity) - welding circuit inductivity (in microhenry)
R (resistance) - welding circuit resistance (in mOhm)

See the "L/R alignment" section for further details.

AC setup (for rod electrodes)

General

This setup is only available with MagicWave power sources.


Opening the AC setup



1

Press the Mode button to select the MMA welding mode

The image for the rod electrode welding parameter is shown on the display, e.g.:



2

Press Menu key

The main menu appears:



3


Use the adjusting dial to select "AC setup" (turn the adjusting dial)



4

Press the adjusting dial

The AC setup parameters are shown:




The power source is now in AC setup.


Changing welding parameters




- 1 Select the desired welding parameter by turning the adjusting dial:



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:



- 3 Change the welding parameter value by turning the adjusting dial:



- 4 To apply the welding parameter value press the adjusting dial




Exiting AC setup



- 1 Press Menu key
or



- Select the arrow symbol by turning the adjusting dial





- Press the adjusting dial


The main menu appears:



- 2 Press Menu key
or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The image for the rod electrode welding parameter is shown:



Welding parameters in AC setup

"Minimum" and "maximum" are used for setting ranges that differ according to power source, wire-feed unit, welding program, etc.

AC frequency

Unit	Hz
Setting range	Syn / 40 - 250
Factory setting	60
Syn	for mains synchronisation of two power sources for simultaneous AC welding.

Job

General

The following actions can be performed in the Job set-up menu:

Save:	Save settings as a job
Retrieve:	Retrieve jobs for the welding job
Retrieve:	Adjust and modify stored jobs
Delete:	Delete stored jobs

Opening the Job set-up menu




- 1 Press Menu key
The main menu appears, e.g.:



- 2 Use the adjusting dial to select "job" (turn the adjusting dial)



- 3 Press the adjusting dial
The menu items for the job appear:



The power source is now in the Job set-up menu.

Save / retrieve

The 'Save' and 'Retrieve' commands on the Job menu are described in the "Welding" chapter.

Overview

The Job set-up menu comprises the following sections:

- Optimise job
- Delete a job

Optimising a job

Optimising a job



- 1 Use the adjusting dial to select "optimise" (turn the adjusting dial)

Job	
Save	
Retrieve	
Optimise	
Delete	



- 2 Press the adjusting dial
The first "Optimise job" screen or the last job to be selected or saved appears:

Optimise job	
Job	13
Job empty	

Optimise job	
Job	6
Electrode diam.	2.4 mm
Starting current	50 %
Upslope	0.50 s

Example job



- 3 Press the adjusting dial to select the job
The job to be optimised can now be selected:

Optimise job	
Job	13
Job empty	

Optimise job	
Job	6
Electrode diam.	2.4 mm
Starting current	50 %
Upslope	0.50 s



- 4 Use the adjusting dial to select the number of the job to be optimised (turn the adjusting dial)

Optimise job	
Job	2
Job empty	

Optimise job	
Job	2
Electrode diam.	2.4 mm
Starting current	50 %
Upslope	0.50 s



- 5 Press the adjusting dial
The welding parameters for the job to be optimised appear:

Optimise job	
Job	2
Electrode diam.	1.6 mm
Starting current	62 %
Upslope	1.2 s



- 6 Turn the adjusting dial to select the welding parameters to be modified, e.g.:

Optimise job	
Job	2
Electrode diam.	1.6 mm
Starting current	62 %
Upslope	1.2 s



- 7 Press the adjusting dial
The value of the selected welding parameter can now be changed:

Optimise job	
Job	2
Electrode diam.	1.6 mm
Starting current	62 %
Upslope	1.2 s



- 8 Change the welding parameter value by turning the adjusting dial:

Optimise job	
Job	2
Electrode diam.	1.6 mm
Starting current	55 %
Upslope	1.2 s



- 9 To apply the welding parameter value press the adjusting dial

Optimise job	
Job	2
Electrode diam.	1.6 mm
Starting current	55 %
Upslope	1.2 s

Renaming a job



- 1 In the "Optimise job" menu item, turn the adjusting dial to select "Job name"

Optimise job	
Job	1
Jobname	Side_up_01
Electrode diam.	2.4 mm
Starting current	50 %



- 2 Press the adjusting dial
The "Name job" screen appears:

Name job	
Job 1	Side_up_01
A B C D E F G H I J K L M	
N O P Q R S T U V W X Y Z	
Cancel	OK



- 3 Delete the existing job name: Turn the adjusting dial and select 'Del'

Name job	
Job 1	Side_up_01
/ \ _ - + * ~ # % & . , 0	
1 2 3 4 5 6 7 8 9 Del	
Cancel	OK



- 4 If you press the adjusting dial the last character will be deleted:

Name job	
Job 1	Side_
/ \ _ - + * ~ # % & . , 0	
1 2 3 4 5 6 7 8 9 Del	
Cancel	OK



- 5 Turn the adjusting dial to select the desired letters / numbers:

Name job	
Job 1	Side_
a b c d e f g h i j k l m	
n o p q r s t u v w x y z	
Cancel	OK



- 6 Then press the adjusting dial in order to enter these letters / numbers:

Name job	
Job 1	Side_d
a b c d e f g h i j k l m	
n o p q r s t u v w x y z	
Cancel	OK



- 7 Press the button on the right (OK) in order to accept the name

Name job	
Job 1	Side_down_02
/ \ _ - + * ~ # % & . , 0	
1 2 3 4 5 6 7 8 9 Del	
Cancel	OK

The new job name is applied and the "Optimise job" menu item will appear:

Optimise job	
Job	1
Jobname	Side_down_02
Electrode diam.	2.4 mm
Starting current	50 %

Finish optimising job



1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

Optimise job	
Job	2
Electrode diam.	1.6 mm
Starting current	55 %
Upslope	1.2 s



- Press the adjusting dial

The menu items for the job appear:

Job
Save
Retrieve
Optimise
Delete



2 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

Job
Save
Retrieve
Optimise
Delete



- Press the adjusting dial

The current set-up menu is displayed:

Menu
AC-setup
Gas-setup
Cold wire-setup
Job



3 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The current welding parameters will appear, e.g.:



TIG welding parameters for 2-step mode (main current welding parameter selected)

Adjustable TIG parameters

Electrode diam.

Electrode diameter

Unit	mm
Setting range	Off / 0.1 - 4.8

Starting current

Unit	% (of main current)
Setting range	30 - 200 AC, 0 - 200 DC

UpSlope

Unit	s
Setting range	0.0 - 9.9

Main current

Unit	A	
Setting range	MW 2200 Comfort 3 - 220	TT 2200 Comfort 3 - 220
	MW 2500 Comfort 3 - 250	TT 2500 Comfort 3 - 250
	MW 3000 Comfort 3 - 300	TT 3000 Comfort 3 - 300
	MW 4000 Comfort 3 - 400	TT 4000 Comfort 3 - 400
	MW 5000 Comfort 3 - 500	TT 5000 Comfort 3 - 500

Reduced current

in 4-step mode

Unit	% (of main current)
Setting range	0 - 100

DownSlope

Unit	s
Setting range	0.0 - 9.9

Final current

Unit	% (of main current)
Setting range	0 - 100

Jobslope

For changing to another job during welding. Jobslope is the time that it takes for the welding current to adjust seamlessly from the present job to the next.

Unit	s
Setting range	Off / 0.1 - 9.9

NOTE!

Switching over from one job to the next without interrupting welding is only possible with a JobMaster TIG welding torch, robot interface or field bus.

Pre-flow

Gas pre-flow time

Unit	s
Setting range	0.0 - 9.9

Post-flow. I_{min}

Post-flow at I_{min}

Gas post-flow time at minimum welding current (minimum gas post-flow time)

Unit	s
Setting range	0 - 25
Factory setting	5

Post-flow I_{max}

Post-flow at I_{max}


Increase in gas post-flow time at maximum welding current

Unit	s
Setting range	0 - 40/Aut
Factory setting	Aut

The value set for "Post-flow I_{max}" only applies if the maximum welding current actually has been set. The actual value is derived from the present welding current. With a medium welding current, for example, the actual value will be one-half of the value set for "Post-flow I_{max}".

IMPORTANT! The values set for the "Post-flow I_{min}" and "Post-flow I_{max}" parameters are added together. For example, if both welding parameters are at maximum (25 s / 40 s), the gas post-flow will last:

- 25 s at minimum welding current
- 65 s at maximum welding current
- 37.5 s if the welding current is exactly half the maximum, etc.



Legend:

- (1).... Gas post-flow time at any given moment
 (2).... Welding current at any given moment

G-H.... Post-flow I_{max}

G-L Post-flow I_{min}

Gas post-flow time as a function of the welding current

If Aut is selected, the gas post-flow time is calculated automatically. This takes the selected welding process (AC or DC welding) into account.

Tacking function

for the TIG DC welding process: Duration of the pulsed welding current at the start of tacking

Unit	s
Setting range	OFF / 0.1 - 9.9 / ON
ON	The pulsed welding current remains in effect until the end of the tacking operation
0.1 - 9.9 s	The set time begins with the UpSlope phase. After the end of the pre-set time period, welding continues with a constant welding current; any pulsing parameters that have been set are available.
OFF	The tacking function is deactivated

Pulse frequency

Unit	Hz / kHz
Setting range	OFF / 0.20 Hz - 2.00 kHz

The selected pulse frequency is also used for the reduced current I_2 .

IMPORTANT! If the pulse frequency is set to "OFF":

- the Duty Cycle, Base current and Wirefeed spd 2 (from the cold wire setup) welding parameters are not available
- the wire speed set on the control panel is used for constant wirefeed at a constant welding current.

Setting the pulse frequency:

0.2 Hz to 5 Hz	Thermal pulsing (out-of-position welding, automated welding)
1 kHz to 2 kHz	Arc-stabilising pulsing (stabilising the arc at a low welding current)

Duty Cycle

The ratio of pulse duration to base current duration when a pulse frequency has been set

Unit	%
Setting range	10 - 90

Base current

Unit	% (of main current I_1)
Setting range	0 - 100

Polarity

Unit	-
Setting range	AC (only MagicWave) / DC- / DC+

AC frequency

only with MagicWave for the TIG AC welding process

Unit	Hz
Setting range	Syn / 40 - 250
Syn	for mains synchronisation of two power sources for simultaneous AC welding.

IMPORTANT! If using the "Syn" setting, remember to check the "Phase sync." parameter in AC setup 2nd.

Low frequency	soft, wide arc with shallow heat input
High frequency	focused arc with deep heat input

AC-current offset

only with MagicWave for the TIG AC welding process

Unit	%
Setting range	-70 to +70
+70	highest fusing power, lowest cleaning action
-70	narrow arc, deep heat input, faster welding speed

Balance

only on MagicWave for TIG AC welding process

Unit	-
Setting range	-5 - +5
-5:	wide arc with shallow heat input
+5:	highest cleaning action, lowest fusing power

Spot welding time

Unit	s
Setting range	OFF / 0.05 - 25.0

If a value has been set for the spot welding time, "2-step mode" will work in the same way as spot welding mode.

Starting current time

Unit	s
Setting range	OFF / 0.01 - 9.9

The starting current time t-S specifies the duration of the starting-current phase I_s .

IMPORTANT! The starting current time only applies in 2-step mode. In 4-step mode, the duration of the starting-current phase I_s is controlled using the torch trigger

Final current time

Unit	s
Setting range	OFF / 0.01 - 9.9

The final current time t-E specifies the duration of the final current phase I_E.

IMPORTANT! The final current time only applies in 2-step mode. In 4-step mode, the duration of the final current phase I_E is controlled with the torch trigger (see: "TIG operating modes").

Current crctn.

Main current I1 correction range for job retrieval

Unit	%
Setting range	OFF / 1 - 100

IMPORTANT! The I1 correction range only applies to job retrieval.

In the jobs, all the settings are permanently saved, i.e. cannot be changed. However, the parameter "current crctn" permits subsequent correction of the main current I1.

Example

The setup parameter "current crctn" has been set to 30%:

- The welding current I1 can then be decreased or increased by up to 30%.

IMPORTANT! Every subsequent correction of the main current I1 is reset (i.e. cancelled) when the power source is switched off.

Operating mode

Unit	-
Setting range	2t / 4t
2t	2-step mode
4t	4-step mode

Wirefeed spd

Wire speed 1 (when cold wirefeeder option is available)

Unit	m/min	ipm
Setting range	OFF / 0.1 - max.	OFF / 3.9 - max.

Wirefeed spd 2

Wire speed 2

Unit	% (of the wire speed)
Setting range	0 - 100

If a value is set for both the "wire speed 2" and "pulse frequency" setup parameters, then the wire speed alternates between the following values in sync with the pulse frequency of the welding current:

- Wire speed 1
- Wire speed 2

Start-delay

Delay in the start of wirefeeding from beginning of the main current phase

Unit	s
Setting range	OFF / 0.1 - 9.9

End-delay

Delay in the end of wirefeeding from end of the main current phase

Unit	s
Setting range	OFF / 0.1 - 9.9

Wire withdrawal

Unit	mm	in.
Setting range	OFF / 1 - 50	OFF / 0.04 - 1.97

IMPORTANT! Wire withdrawal prevents the welding wire from burning at the end of welding. Before the welding current is switched off, the wire is withdrawn by the set value. A prerequisite for this function is that the arc has ignited.

Wire threading

Feeder inching speed

Unit	m/min	ipm.
Setting range	1.0 - max.	39.37 - max.

Adjustable rod electrode parameters**Main current**

Unit	A	
Setting range	MW 2200 Comfort 10 - 180	TT 2200 Comfort 10 - 180
	MW 2500 Comfort 10 - 250	TT 2500 Comfort 10 - 250
	MW 3000 Comfort 10 - 300	TT 3000 Comfort 10 - 300
	MW 4000 Comfort 10 - 400	TT 4000 Comfort 10 - 400
	MW 5000 Comfort 10 - 500	TT 5000 Comfort 10 - 500

Arc-force dynamic

In order to obtain optimum welding results, it will sometimes be necessary to set the arc-force dynamic function.

Unit	% (of main current)
Setting range	0 - 100
0	soft, low-spatter arc
100	harder, more stable arc

Functional principle:

at the instant of droplet transfer or in the event of a short circuit, there is a momentary rise in amperage. In order to obtain a stable arc, the welding current is temporarily increased. If the rod electrode threatens to sink into the weld pool, this measure prevents the weld pool solidifying, as well as preventing more prolonged short circuiting of the arc. This largely prevents the rod electrode from sticking.

Jobslope

For changing to another job during welding. Jobslope is the time that it takes for the welding current to adjust seamlessly from the present job to the next.

Unit	s
Setting range	Off / 0.1 - 9.9

NOTE!

Switching over from one job to the next without interrupting welding is only possible with a JobMaster TIG welding torch, robot interface or field bus.

Starting current

Unit	% (of main current)
Setting range	30 - 200 AC, 0 - 200 DC

Starting current time


Unit	s
Setting range	OFF / 0.01 - 9.9

The starting current time t_S specifies the duration of the starting-current phase I_S .

Char.

To select characteristics

Unit	
Setting range	con or 0.1 - 20 or P
Factory setting	con



Characteristics that can be selected using the characteristic function

"con" parameter (constant welding current)

- If the "con" parameter is set, the welding current will be kept constant, irrespective of the welding voltage. This results in a vertical characteristic (4).
- The "con" parameter is especially suitable for rutile electrodes and basic electrodes, as well as for arc air gouging.
- For arc air gouging, set the arc-force dynamic to "100".

Parameter "0.1 - 20" (drooping characteristic with adjustable slope)

- Parameter "0.1 - 20" is used to set a drooping characteristic (5). The setting range extends from 0.1 A / V (very steep) to 20 A / V (very flat).
- Setting a flat characteristic (5) is only advisable for cellulose electrodes.

NOTE!


When setting a flat characteristic (5), set the arc-force dynamic to a higher value.

"P" parameter (constant welding power)

- If the "P" parameter is set, the welding power is kept constant, irrespective of the welding voltage and welding current. This results in a hyperbolic characteristic (6).
- The "P" parameter is particularly suitable for cellulose electrodes.

NOTE!

If there are problems with a rod electrode tending to "stick", set the arc-force dynamic to a higher value.



Settings example: $I_1 = 250 \text{ A}$, arc-force dynamic = 50

The characteristics (4), (5) and (6) shown here apply when using a rod electrode whose characteristic corresponds to the load line (1) at a given arc length.

Depending on what welding current (I) has been set, the point of intersection (operating point) of characteristics (4), (5) and (6) will be displaced along the load line (1). The operating point provides information on the actual welding voltage and the actual welding current.

Where the welding current (I_1) is permanently set, the operating point may migrate along the characteristics (4), (5) and (6) depending on the welding voltage at that moment in time. The welding voltage U is dependent upon the arc length.

If the arc length changes, e.g. in accordance with the load line (2), the resulting operating point will be the point where the corresponding characteristic (4), (5) or (6) intersects with the load line (2).

Applies to characteristics (5) and (6): Depending upon the welding voltage (arc length), the welding current (I) will also become either smaller or larger, even though the value set for I_1 remains the same.

Polarity

Unit

-

Setting range

AC (only MagicWave) / DC- / DC+

AC frequency

only with MagicWave for the TIG AC welding process

Unit	Hz
Setting range	Syn / 40 - 250
Syn	for mains synchronisation of two power sources for simultaneous AC welding.

IMPORTANT! If using the "Syn" setting, remember to check the "Phase sync." parameter in AC setup 2nd.

Low frequency	soft, wide arc with shallow heat input
High frequency	focused arc with deep heat input

Balance

only on MagicWave for TIG AC welding process


Unit	-
Setting range	-5 - +5
-5:	wide arc with shallow heat input
+5:	highest cleaning action, lowest fusing power

Deleting a job

Deleting a job




- 1 Use the adjusting dial to select "Delete" (turn the adjusting dial)




- 2 Press the adjusting dial
The first "Delete job" screen is displayed:



- 3 Turn the adjusting dial to select the job for deletion:



- 4 Press the right button
The second "Delete job" screen is displayed:



- 5 Press the button on the left or right



Left button (No): Do not delete job, return to first "Delete job" screen




Press right button (Yes): the selected job number will be deleted

The third "Delete job" screen is displayed:



6 Press the right button

The menu items for the job appear:




7 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The current set-up menu is displayed:





8 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial



- Press the adjusting dial

The current welding parameters are displayed e.g.:



TIG welding parameters for 2-step mode (main current welding parameter selected)

Basic setting

General

The basic settings can be called up in the menu when TIG 2-step mode, TIG 4-step mode or manual metal arc welding mode is selected.

Opening the basic settings



- 1 Press Menu key
The main menu appears:



TIG main menu




Rod electrode main menu



- 2 Use the adjusting dial to select "Basic setting" (turn the adjusting dial)



- 3 Press the adjusting dial
The basic settings parameters appear:



The power source is now in the basic settings.

Changing welding parameters



- 1 Select the desired welding parameter by turning the adjusting dial:

Basic setting	
Language	GB
Unit	metr.
Contrast	20 %
Factory	



- 2 To set the welding parameter, press the adjusting dial
The value of the selected welding parameter can now be changed:

Basic setting	
Language	GB
Unit	metr.
Contrast	20 %
Factory	



- 3 Change the welding parameter value by turning the adjusting dial:

Basic setting	
Language	GB
Unit	imperial
Contrast	20 %
Factory	



- 4 To apply the welding parameter value press the adjusting dial

Basic setting	
Language	GB
Unit	imperial
Contrast	20 %
Factory	

Exiting basic settings



1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

Basic setting	
Language	GB
Unit	imperial
Contrast	20 %
Factory	



- Press the adjusting dial

The relevant main menu appears:

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	

TIG main menu

Menu	
Rod elect. Setup	
AC-setup	
Job	
Basic setting	

Rod electrode main menu



2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	



- Press the adjusting dial

The image for the currently selected mode is shown, e.g.:



TIG welding parameters for 2-step mode

Basic setting parameters

"Minimum" and "maximum" are used for setting ranges that differ according to power source, cold wire-feed unit, welding program, etc.

Language

Unit	-		
Setting range	D / GB / F / I / E / CZ / S / P / NL / PL		
Factory setting	D		
D	German	E	Spanish
GB	English	CZ	Czech
F	French	S	Swedish
I	Italian	P	Brazilian Portuguese
		NL	Dutch
		PL	Polish

Unit

Setting determines whether metric or imperial units are shown

Unit	-	
Setting range	metr./imperial	
Factory setting	metr.	
metr.	Metric units (e.g. mm, m/min, l/min, etc.)	
imperial	Imperial units (e.g. in., ipm, cfh, etc.)	

Contrast

For setting the display contrast

Unit	%
Setting range	0 - 100
Factory setting	20

Factory

For resetting the welding machine

See the "Factory - resetting the welding machine" section for further details.

Info

General

The info screen can be called up in the menu when TIG 2-step mode, TIG 4-step mode or rod electrode welding mode is selected.

Calling up the info screen



- 1 Press Menu key
The main menu appears:




TIG main menu




Rod electrode main menu



- 2 Use the adjusting dial to select "Info" (turn the adjusting dial)



- 3 Press the adjusting dial
The info screen appears:



IMPORTANT! The entries on the info screen are read-only data and cannot be edited or set.

Exiting the info screen



1 Press Menu key

or



- Select the arrow symbol by turning the adjusting dial

Info	
Firmware	v1.1.13
UST software	v4.26.37
Arc burn time	1763.2 h
Coolerflow	0.00 l/min



- Press the adjusting dial

The relevant main menu appears:

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	

TIG main menu

Menu	
Rod elect. Setup	
AC-setup	
Job	
Basic setting	

Rod electrode main menu



2 Press Menu key

or




- Select the arrow symbol by turning the adjusting dial

Menu	
TIG-setup	
AC-setup	
Gas-setup	
Cold wire-setup	



- Press the adjusting dial

The image for the currently selected mode is shown, e.g.:



TIG welding parameters for 2-step mode

Entries on the info screen

Firmware

Current display/control panel firmware

UST Software

Current software of the power source control board UST

Arc burn time

Arc time

Actual total arc burn time since using for the first time

Coolerflow

Coolant flow

Current coolant flow rate for a connected cooling unit in l/min

Lock keys

General

To prevent welding parameters or settings from being changed either intentionally or unintentionally, the 'Lock keys' function can be activated on the power source.

Lock keys



- 1 Press Menu key

The main menu appears:



TIG main menu



Rod electrode main menu



- 2 Use the adjusting dial to select "Lock keys" (turn the adjusting dial)



- 3 Press the adjusting dial


The keys are locked. If a key is pressed, the 'Keylock' screen will appear:




Unlock keys again



- 1 Press Menu key
The 'Lock/unlock keys' screen appears:



- 2 Press the key on the right (OK) within 3 seconds
The keys are unlocked and the image for the currently selected mode is shown, e.g.:



TIG welding parameters for 2-step mode (main current welding parameter selected)

Factory - for resetting the welding machine

General

The welding machine can be reset in the menu when TIG 2-step mode, TIG 4-step mode or rod electrode welding mode is selected.

NOTE!


When the welding machine is reset, all the personal settings in the set-up menu are lost.

Jobs are not deleted when the welding machine is reset - these are preserved. The parameter settings in the second level of the set-up menu are not deleted either.


Factory - for re-setting the welding machine



- 1 Opening the basic settings
- 2 Select 'Factory' by turning the adjustment dial:



- 3 Press the adjusting dial to display the factory screen




Press the left button to cancel




Press the right button to reset the welding machine

The welding machine is reset and a confirmation screen appears:



- 4 If you press the button on the right the basic settings will appear:




L/R alignment

Abbreviations

L = Welding circuit inductivity, μH (Microhenry)
 R = Welding circuit inductivity, mOhm (Milliohm)

General information on welding circuit inductivity L

The way that the hosepack is arranged has a very significant effect on the weld properties. Particularly with pulsed-arc welding and AC welding, a high welding circuit inductivity may occur, depending on the length of the hosepack and on the way that it is arranged. The result is that the current rise is restricted.



Correct arrangement of the hosepack

Changing the way the hosepack is arranged may help to improve the welding results. The hosepack must be laid out as shown in the illustration.

General information on welding circuit resistance R

Measuring the welding circuit resistance "r" provides information on the overall resistance of the torch hosepack, welding torch, workpiece and grounding (earthing) cable.

If an increased welding circuit resistance is detected, e.g. after changing the torch, this may mean that the following components are faulty:

- Torch hosepack
- Welding torch
- Grounding (earthing) connection to the workpiece
- Grounding (earthing) cable

L/R alignment

Calibration of welding circuit inductivity and resistance can be done both in TIG setup 2nd and rod electrode setup 2nd.

NOTE!

L/R alignment must be carried out separately for each welding process.


- 1 Enter TIG setup 2nd or rod electrode setup 2nd



- 2 Select "L/R align." by turning the adjusting dial:



- 3 Press the adjusting dial
The first L/R alignment screen is displayed:



In the following L/R alignment screens, pressing the left button takes you back to the previous screen.



- 4 Press the right arrow key
The second L/R alignment screen is displayed:



- 5 Follow the instructions shown

IMPORTANT! Make sure that the contact between the earthing clamp and the workpiece and electrode and workpiece is on a cleaned section of the workpiece.


While the measurement is being performed, the cooling unit and the cold wirefeeder are deactivated.

During manual metal arc welding, place the electrode holder instead of the tungsten electrode fully on the workpiece.




- 6 Press the right arrow key

After R/L alignment, a confirmation and the current welding circuit resistance will be shown:



- 7 Press the right arrow key

Depending on the mode selected, TIG setup 2nd or rod electrode setup 2nd is displayed:



Troubleshooting and maintenance

Troubleshooting

General

The digital power sources are equipped with an intelligent safety system. This means that apart from the fuse for the coolant pump, it has been possible to dispense with fuses entirely. After a possible malfunction or error has been remedied, the power source can be put back into normal operation again without any fuses having to be replaced.

Safety



WARNING!

Work that is carried out incorrectly may result in serious injury or damage to property.

- ▶ All the work described below must only be carried out by trained and qualified personnel.
- ▶ Do not carry out any of the work described below until you have fully read and understood this document.
- ▶ Do not carry out any of the work described below until you have fully read and understood all of the documents relating to the system components, in particular the safety rules.



WARNING!

An electric shock can be fatal.

Before starting the work described below:

- ▶ Turn the power source mains switch to the "O" position
- ▶ Disconnect the power source from the grid
- ▶ Ensure that the power source remains disconnected from the mains until all work has been completed
- ▶ After opening the device, use a suitable measuring instrument to check that electrically charged components (e.g. capacitors) have been discharged.



WARNING!

An inadequate ground conductor connection can cause serious injury or damage.








The housing screws provide a suitable ground conductor connection for earthing the housing.








- ▶ The housing screws must never be replaced with different screws unless a reliable ground conductor connection is established.








Displayed service codes








If any error message that is not described here appears on the display, then the fault is one that can only be rectified by our After-Sales Service. Make a note of the error message shown in the display and of the serial number and configuration of the power source, and contact our After-Sales Service team with a detailed description of the error.















The service code can be hidden by pressing 'OK'. If the error persists, the service code will reappear after a short delay. If a fault on the device is rectified then the service code will not appear again.


<div>E1</div> <div>  No welding program has been selected. </div> <div>OK ►</div>	<div>Cause: No preconfigured program has been selected</div> <div>Remedy: Select a configured program</div>
<div>E2</div> <div>  Overtemperature in second. circuit of machine </div> <div>OK ►</div>	<div>E2 - E4</div> <div>Cause: Overtemperature in the secondary circuit of the power source</div> <div>Remedy: Allow power source to cool down</div>
<div>E5</div> <div>  Overtemperature in primary circuit of machine </div> <div>OK ►</div>	<div>E5 - E10</div> <div>Cause: Overtemperature in the primary circuit of the power source</div> <div>Remedy: Allow power source to cool down</div>
<div>E11</div> <div>  Error in temperature sensor </div> <div>OK ►</div>	<div>Cause: Temperature sensor fault (short circuit or break)</div> <div>Remedy: Contact After-Sales Service</div>
<div>E17</div> <div>  DSP error </div> <div>OK ►</div>	<div>E17, E20, E21, E29, E35, E36</div> <div>Cause: Fault in central control and regulation unit</div> <div>Remedy: Contact After-Sales Service</div>
<div>E18</div> <div>  DSP reports a power module error </div> <div>OK ►</div>	<div>Cause: Fault in power module</div> <div>Remedy: Contact After-Sales Service</div>
<div>E19</div> <div>  Primary overcurrent </div> <div>OK ►</div>	<div>Cause: Primary overcurrent</div> <div>Remedy: Contact After-Sales Service</div>

<div> <div>E30</div> <div>  Error in wirefeed system </div> <div>OK ▶</div> </div>	<p>When using power sources with a cold wire-feed unit</p> <p>Cause: Fault in cold wire-feed unit</p> <p>Remedy: Check cold wire-feed unit</p>
<div> <div>E33</div> <div>  Overtemperature in control circuit </div> <div>OK ▶</div> </div>	<p>Cause: Overtemperature in the control circuit</p> <p>Remedy: Allow power source to cool down</p>
<div> <div>E38</div> <div>  Robot not ready </div> <div>OK ▶</div> </div>	<p>If the power source is being used with a robot interface or a field bus</p> <p>Cause: Robot not ready</p> <p>Remedy: Initialise "Robot ready" signal, initialise "Source error reset" signal (N.B. "Source error reset" only available in conjunction with ROB 5000 and field bus coupler for robot control)</p>
<div> <div>E39</div> <div>  No coolant flow </div> <div>OK ▶</div> </div>	<p>Cause: Cooling unit flow watchdog has been triggered</p> <p>Remedy: Check the cooling unit; if necessary, top up the coolant or bleed the system as described in "Putting the cooling unit into service"</p>
<div> <div>E40</div> <div>  The Licence key is not correct. </div> <div>OK ▶</div> </div>	<p>Cause: The software activation code is incorrect</p> <p>Remedy: Check the software activation code, try again</p>
<div> <div>E49</div> <div>  Phase failure </div> <div>OK ▶</div> </div>	<p>Cause: Phase failure in power supply</p> <p>Remedy: Check the mains fuse, the mains lead and the mains plug</p>
<div> <div>E50</div> <div>  Symmetry error </div> <div>OK ▶</div> </div>	<p>Cause: Indirect symmetry error</p> <p>Remedy: Contact After-Sales Service</p>


<div> <div>E51</div> <div>  Mains undervoltage </div> <div>OK ▶</div> </div>	<p>Cause: Mains undervoltage: The mains voltage has dropped below the lower limit of the tolerance range (see section "Technical data")</p> <p>Remedy: Check the mains voltage</p>
<div> <div>E52</div> <div>  Mains overvoltage </div> <div>OK ▶</div> </div>	<p>Cause: Mains overvoltage: The mains voltage has exceeded the upper limit of the tolerance range (see section "Technical data")</p> <p>Remedy: Check the mains voltage</p>
<div> <div>E53</div> <div>  Earth-fault error </div> <div>OK ▶</div> </div>	<p>Cause: The earth current watchdog has triggered the safety cut-out of the power source.</p> <p>Remedy: Switch off the power source, wait for 10 seconds and then switch it on again. If you have tried this several times and the error keeps recurring, contact After-Sales Service.</p>
<div> <div>E54</div> <div>  Wire-stick </div> <div>OK ▶</div> </div>	<p>Cause: Wire stick</p> <p>Remedy: Correct wire short circuit</p>
<div> <div>E55</div> <div>  Ignition time-out </div> <div>OK ▶</div> </div>	<p>Cause: Ignition time-out function is active: no current started flowing before the end of the time specified in the set-up menu. The safety cut-out of the power source has been triggered.</p> <p>Remedy: Press the torch trigger repeatedly; clean the workpiece surface; if necessary, increase the time until the safety cut-out is triggered in the set-up menu: level 2</p>
<div> <div>E56</div> <div>  Wire end </div> <div>OK ▶</div> </div>	<p>Cause: Wire end - the wire-end check option has detected that there is no more welding wire available</p> <p>Remedy: Insert new wirespool</p>
<div> <div>E58</div> <div>  Arc-break watchdog </div> <div>OK ▶</div> </div>	<p>Cause: Arc break</p> <p>Remedy: Press the torch trigger repeatedly; clean the surface of the workpiece</p>

<div>E59</div> <div>  Secondary over-voltage </div> <div>OK ►</div>	<div>Cause: Secondary overvoltage: safety cut-out has tripped.</div> <div>Remedy: Contact After-Sales Service</div>
<div>E62</div> <div>  TP08 overtemperature </div> <div>OK ►</div>	<div>Cause: Overtemperature on TP 08 remote control</div> <div>Remedy: Allow TP 08 remote control to cool down</div>
<div>E63</div> <div>  Interface error </div> <div>OK ►</div>	<div>Cause: Interface fault</div> <div>Remedy: Contact After-Sales Service</div>
<div>E65</div> <div>  Overtemperature in cooling unit </div> <div>OK ►</div>	<div>Cause: Thermostat on cooling unit has tripped</div> <div>Remedy: Wait until the end of the cooling phase, i.e. until "Hot H2O" is no longer displayed. ROB 5000 or field bus coupler for robot control: Before resuming welding, set the "Source error reset" signal.</div>
<div>E66</div> <div>  Overtemperature in JobMaster welding torch </div> <div>OK ►</div>	<div>Cause: Overtemperature in JobMaster welding torch</div> <div>Remedy: Allow the JobMaster welding torch to cool down</div>
<div>E71</div> <div>  Current or voltage limit violation </div> <div>OK ►</div>	<div>Cause: The upper/lower current or voltage limit was exceeded</div> <div>Remedy: Check welding parameters</div>
<div>E71.1</div> <div>  Limit-exceed of upper current limit. </div> <div>OK ►</div>	<div>Cause: The upper current limit was exceeded</div> <div>Remedy: Check welding parameters</div>

<div data-bbox="416 152 866 320"> <div data-bbox="424 185 528 297"></div> <div data-bbox="539 152 802 297"> <div data-bbox="598 152 694 181">E71.2</div> <div data-bbox="539 185 802 297">Limit-exceed of lower current limit.</div> </div> </div> <div data-bbox="655 331 866 376"> <div data-bbox="727 338 783 367">OK</div> <div data-bbox="831 338 858 367"></div> </div>	<div data-bbox="898 141 1447 376"> <div data-bbox="898 141 1447 203">Cause: The current dropped below the lower limit</div> <div data-bbox="898 215 1447 246">Remedy: Check welding parameters</div> </div>
<div data-bbox="416 409 866 577"> <div data-bbox="424 443 528 555"></div> <div data-bbox="539 409 802 555"> <div data-bbox="598 409 694 439">E71.3</div> <div data-bbox="539 443 802 555">Limit-exceed of upper voltage limit.</div> </div> </div> <div data-bbox="655 577 866 622"> <div data-bbox="727 584 783 613">OK</div> <div data-bbox="831 584 858 613"></div> </div>	<div data-bbox="898 398 1447 633"> <div data-bbox="898 398 1447 461">Cause: The upper voltage limit was exceeded</div> <div data-bbox="898 472 1447 504">Remedy: Check welding parameters</div> </div>
<div data-bbox="416 667 866 835"> <div data-bbox="424 701 528 813"></div> <div data-bbox="539 667 802 835"> <div data-bbox="598 667 694 696">E71.4</div> <div data-bbox="539 701 802 835">Limit-exceed of lower voltage limit.</div> </div> </div> <div data-bbox="655 835 866 880"> <div data-bbox="727 842 783 871">OK</div> <div data-bbox="831 842 858 871"></div> </div>	<div data-bbox="898 656 1447 891"> <div data-bbox="898 656 1447 719">Cause: The voltage dropped below the lower limit</div> <div data-bbox="898 730 1447 761">Remedy: Check welding parameters</div> </div>
<div data-bbox="416 925 866 1093"> <div data-bbox="424 958 528 1070"></div> <div data-bbox="539 925 802 1093"> <div data-bbox="598 925 694 954">E72</div> <div data-bbox="539 958 802 1093">Machine configuration has changed</div> </div> </div> <div data-bbox="655 1093 866 1137"> <div data-bbox="727 1099 783 1128">OK</div> <div data-bbox="831 1099 858 1128"></div> </div>	<div data-bbox="898 913 1447 1149"> <div data-bbox="898 913 1447 976">Cause: The welding device configuration has been changed</div> <div data-bbox="898 987 1447 1019">Remedy: Check LHSB link</div> </div>
<div data-bbox="416 1182 866 1350"> <div data-bbox="424 1216 528 1328"></div> <div data-bbox="539 1182 802 1350"> <div data-bbox="598 1182 694 1211">Error 73</div> <div data-bbox="539 1216 802 1350">HOST error</div> </div> </div> <div data-bbox="655 1350 866 1395"> <div data-bbox="727 1357 783 1386">OK</div> <div data-bbox="831 1357 858 1386"></div> </div>	<div data-bbox="898 1171 1447 1406"> <div data-bbox="898 1171 1447 1234">Cause: No connection to power source</div> <div data-bbox="898 1245 1447 1276">Remedy: Check connection to power source and its software</div> </div>
<div data-bbox="416 1440 866 1608"> <div data-bbox="424 1473 528 1585"></div> <div data-bbox="539 1440 802 1608"> <div data-bbox="598 1440 694 1469">E73</div> <div data-bbox="539 1473 802 1608">Cannot connect to power source.</div> </div> </div> <div data-bbox="655 1608 866 1653"> <div data-bbox="727 1615 783 1644">OK</div> <div data-bbox="831 1615 858 1644"></div> </div>	
<div data-bbox="416 1697 866 1865"> <div data-bbox="424 1731 528 1843"></div> <div data-bbox="539 1697 802 1865"> <div data-bbox="598 1697 694 1727">E78</div> <div data-bbox="539 1731 802 1865">Emergency Stop - safety circuit is open</div> </div> </div> <div data-bbox="655 1865 866 1910"> <div data-bbox="727 1872 783 1901">OK</div> <div data-bbox="831 1872 858 1901"></div> </div>	<div data-bbox="898 1686 1447 1921"> <div data-bbox="898 1686 1447 1749">Cause: Emergency Stop - safety circuit is open</div> <div data-bbox="898 1760 1447 1792">Remedy: Contact After-Sales Service</div> </div>

<div> <div>E79</div> <div>  The VRD has interrupted the process </div> <div>OK ▶</div> </div>	<div> <div>Cause:</div> <div>The VRD (Voltage Reduction Device) function has interrupted the welding process</div> <div>Remedy:</div> <div>Contact After-Sales Service</div> </div>
---	---


Service codes displayed in conjunction with the digital gas control option

<div> <div>E57</div> <div>  Gas flow </div> <div>OK ▶</div> </div>	<div> <div>Cause:</div> <div>The gas watchdog option has detected that there is no gas pressure</div> <div>Remedy:</div> <div>Check protective gas shield supply, connect new gas cylinders or gas cylinder valves/open gas pressure regulator</div> </div>
--	---


Displayed Service codes in conjunction with cold wire-feed unit


The following abbreviations are used for the service codes shown in conjunction with cold wire-feed units:


KD	= Cold wire-feed unit
PPU	= Push-pull unit
vDmin	= minimum wire feed speed
vDmax	= maximum wire feed speed

<div> <div>E30.9.1</div> <div>  Motor supply voltage not reached </div> <div>OK ▶</div> </div>	<div> <div>Cause:</div> <div>The external supply voltage has dropped below the tolerance limit</div> <div>Remedy:</div> <div>Check the external supply voltage</div> </div>
--	---

<div> <div>Cause:</div> <div>Wire-feed unit motor is sticking or defective</div> <div>Remedy:</div> <div>Check or replace the wire-feed unit motor</div> </div>

<div> <div>E30.9.2</div> <div>  Motor supply voltage exceeded </div> <div>OK ▶</div> </div>	<div> <div>Cause:</div> <div>The external supply voltage has dropped below the tolerance limit</div> <div>Remedy:</div> <div>Check the external supply voltage</div> </div>
---	---

<div> <div>E30.12.1</div> <div>  No rotational speed value from wirefeeder motor </div> <div>OK ▶</div> </div>	<div> <div>Cause:</div> <div>No actual speed value from the wire-feed unit motor</div> <div>Remedy:</div> <div>Check actual value and leads, if the error persists contact After-Sales Service</div> </div>
--	---

<div style="border: 1px solid black; padding: 10px; text-align: center;"> <div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;">  </div> <div> E30.12.2 No act. rotational speed value from PPU motor </div> </div> <div style="margin-top: 10px; text-align: center;"> <div style="background-color: black; color: white; padding: 5px 15px; display: inline-block;">OK</div> <div style="font-size: 20px; margin-left: 10px;">▶</div> </div> </div>	<div>Cause: No actual speed value from the wire-feed unit motor</div> <div>Remedy: Check actual value and leads, if the error persists contact After-Sales Service</div>
--	--

Power source - troubleshooting

Power source does not function

Mains switch is on, but indicators are not lit up

Cause: There is a break in the mains lead; the mains plug is not plugged in

Remedy: Check the mains lead, ensure that the mains plug is plugged in

Cause: Mains socket or mains plug faulty

Remedy: Replace faulty parts

Cause: Mains fuse protection

Remedy: Change the mains fuse protection

No welding current

Mains switch is ON, overtemperature indicator is lit up

Cause: Overload

Remedy: Check duty cycle

Cause: Thermostatic safety cut-out has tripped

Remedy: Wait until the power source automatically comes back on after the end of the cooling phase

Cause: The fan in the power source is faulty

Remedy: Contact After-Sales Service

No welding current

Mains switch is on, indicators are lit up

Cause: Grounding (earthing) connection is incorrect

Remedy: Check the grounding (earthing) connection and terminal for correct polarity

Cause: There is a break in the current cable in the welding torch

Remedy: Replace welding torch

Nothing happens when the torch trigger is pressed

Mains switch is on, indicators are lit up

Cause: The control plug is not plugged in

Remedy: Plug in the control plug

Cause: Welding torch or welding torch control line is faulty

Remedy: Replace welding torch

No protective gas shield

All other functions are OK

Cause: Gas cylinder is empty

Remedy: Change the gas cylinder

Cause: Gas pressure regulator is faulty

Remedy: Change the gas pressure regulator

Cause: Gas hose is not fitted or is damaged

Remedy: Fit or change the gas hose

Cause: Welding torch is faulty

Remedy: Change the welding torch

Cause: Gas solenoid valve is faulty

Remedy: Contact After-Sales Service

Poor weld properties

Cause: Incorrect welding parameters

Remedy: Check the settings

Cause: Grounding (earthing) connection is incorrect

Remedy: Check the grounding (earthing) connection and terminal for correct polarity

The welding torch becomes very hot

Cause: The dimensions of the welding torch are inadequate

Remedy: Observe the duty cycle and loading limits

Cause: Only on water-cooled machines: water flow rate is insufficient

Remedy: Check the water level, water flow rate, cleanliness, etc. If the coolant pump is blocked: use a screwdriver - placed on the bushing - to turn the coolant pump shaft

Cause: Only on water-cooled machines: welding parameter 'Cool. unit ctrl' is set to "OFF".

Remedy: In the set-up menu, set welding parameter 'Cool. unit ctrl' to "Aut" or "ON".

Care, maintenance and disposal

General

Under normal operating conditions, the power source requires only a minimum of care and maintenance. However, it is vital to observe some important points to ensure it remains in a usable condition for many years.

Safety



WARNING!

Work that is carried out incorrectly may result in serious injury or damage to property.

- ▶ All the work described below must only be carried out by trained and qualified personnel.
 - ▶ Do not carry out any of the work described below until you have fully read and understood this document.
 - ▶ Do not carry out any of the work described below until you have fully read and understood all of the documents relating to the system components, in particular the safety rules.
-



WARNING!

An electric shock can be fatal.

Before starting the work described below:

- ▶ Turn the power source mains switch to the "O" position
 - ▶ Disconnect the power source from the grid
 - ▶ Ensure that the power source remains disconnected from the mains until all work has been completed
 - ▶ After opening the device, use a suitable measuring instrument to check that electrically charged components (e.g. capacitors) have been discharged.
-



WARNING!

An inadequate ground conductor connection can cause serious injury or damage.

The housing screws provide a suitable ground conductor connection for earthing the housing.

- ▶ The housing screws must never be replaced with different screws unless a reliable ground conductor connection is established.
-

At every start-up

- Check mains plug, mains cable, welding torch, interconnecting hosepack and ground earth connection for damage
- Check that the device has an all-round clearance of 0.5 m (1 ft. 8 in.) around the device to ensure that cooling air can flow in and out freely

NOTE!

Air inlets and outlets must never be covered, not even partially.

Every 2 months

- If present: clean air filter

Every 6 months



CAUTION!

Danger due to the effect of compressed air.

This can result in damage to property.

- Do not bring the air nozzle too close to electronic components.

1 Dismantle device side panels and clean inside of device with dry, reduced compressed air

2 If a lot of dust has accumulated, clean the cooling air ducts



WARNING!

An electric shock can be fatal!

Risk of electric shock from improperly connected ground cables and equipment grounds.

- When reassembling the side panels, make sure that grounding cables and equipment grounds are properly connected.

Disposal

Dispose of in accordance with the applicable national and local regulations.

Appendix

Technical data

Special voltages



CAUTION!

An inadequately dimensioned electrical installation can cause serious damage.

- The mains lead and its fuse must be dimensioned accordingly.
The technical data shown on the rating plate applies.

MagicWave 2200 Comfort

	MW 2200 Comfort
Mains voltage	230 V
Mains voltage tolerance	-20 % / +15 %
Mains frequency	50/60 Hz
Mains fuse protection (slow-blow)	16 A
Mains connection ¹⁾	No restrictions
Primary continuous power (100% d.c. ²⁾)	3.7 kVA
Cos phi	0,99
Welding current range	
TIG	3 - 220 A
Electrode	10 - 180 A
Welding current at	
10 min/25 °C (77 °F) 40% d.c. ²⁾	220 A
10 min/25 °C (77 °F) 60% d.c. ²⁾	180 A
10 min/25 °C (77 °F) 100% d.c. ²⁾	150 A
10 min/40 °C (104 °F) 35% d.c. ²⁾	220 A
10 min/40 °C (104 °F) 60% d.c. ²⁾	170 A
10 min/40 °C (104 °F) 100% d.c. ²⁾	150 A
Open circuit voltage	88 V
Working voltage	
TIG	10.1 - 18.8 V
Electrode	20.4 - 27.2 V
Striking voltage (U _p)	9.5 kV
The arc striking voltage is suitable for manual operation.	
Degree of protection	IP 23
Type of cooling	AF
Insulation class	B
EMC emission class (in accordance with EN/IEC 60974-10)	A
Dimensions L x W x H (with handle)	485 / 180 / 390 mm 19.1 / 7.1 / 15.4 in.
Weight (without handle)	17.4 kg 38.3 lb.
Weight (with handle)	17.8 kg 39.2 lb.
Mark of conformity	S, CE

**MagicWave
2500 / 3000 Com-
fort**

	MW 2500 Comfort	MW 3000 Comfort
Mains voltage	3 x 400 V	3 x 400 V
Mains voltage tolerance	± 15 %	± 15 %
Mains frequency	50/60 Hz	50/60 Hz
Mains fuse protection (slow-blow)	16 A	16 A
Mains connection ¹⁾	Z _{max} at PCC ³⁾ = 122 mOhm	Z _{max} at PCC ³⁾ = 87 mOhm
Primary continuous power (100% d.c. ²⁾)	4.7 kVA	5.5 kVA
Cos phi	0,99	0,99
Welding current range		
TIG	3 - 250 A	3 - 300 A
Electrode	10 - 250 A	10 - 300 A
Welding current at		
10 min/40 °C (104 °F) 35% d.c. ²⁾	-	300 A
10 min/40 °C (104 °F) 40% d.c. ²⁾	250 A	-
10 min/40 °C (104 °F) 100% d.c. ²⁾	180 A	200 A
Open circuit voltage	89 V	89 V
Working voltage		
TIG	10.1 - 20.0 V	10.1 - 22.0 V
Electrode	20.4 - 30.0 V	20.4 - 32.0 V
Striking voltage (U _p)	10 kV	10 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	B	B
Dimensions L x W x H (with handle)	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.
Weight	26.6 kg 58.64 lb.	28.1 kg 61.95 lb.
Mark of conformity	S, CE	S, CE

**MagicWave
2500 / 3000 Com-
fort MV**

	MW 2500 Comfort MV	MW 3000 Comfort MV
Mains voltage	3 x 200 - 240 V 3 x 400 - 460 V 1 x 200 - 240 V	3 x 200 - 240 V 3 x 400 - 460 V 1 x 200 - 240 V
Mains voltage tolerance	± 10 %	± 10 %
Mains frequency	50 / 60 Hz	50 / 60 Hz
Mains fuse protection (slow-blow)		
3 x 400 - 460 V	16 A	16 A
3 x 200 - 240 V	32 A	32 A
1 x 200 - 240 V	32 A	32 A
Mains connection ¹⁾	Z _{max} at PCC ³⁾ = 122 mOhm	Z _{max} at PCC ³⁾ = 87 mOhm

	MW 2500 Comfort MV	MW 3000 Comfort MV
Primary continuous power (100% d.c. ²⁾)		
3 x 400 - 460 V	4,8 kVA	5,1 kVA
3 x 200 - 240 V	4,4 kVA	4,9 kVA
1 x 200 - 240 V	3,9 kVA	4,3 kVA
Cos phi	0,99	0,99
Welding current range (3-phase)		
TIG	3 - 250 A	3 - 300 A
Electrode	10 - 250 A	10 - 300 A
Welding current range (single phase)		
TIG	3 - 220 A	3 - 220 A
Electrode	10 - 180 A	10 - 180 A
Welding current at 3 x 400 - 460 V		
10 min/40°C (104°F) 35% d.c. ²⁾	-	300 A
10 min/40°C (104°F) 40% d.c. ²⁾	250 A	-
10 min/40°C (104°F) 100% d.c. ²⁾	180 A	190 A
Welding current at 3 x 200 - 240 V		
10 min/40°C (104°F) 30% d.c. ²⁾	-	300 A
10 min/40°C (104°F) 35% d.c. ²⁾	250 A	-
10 min/40°C (104°F) 100% d.c. ²⁾	160 A	180 A
Welding current at 1 x 200 - 240 V		
10 min/40°C (104°F) 40% d.c. ²⁾	220 A	-
10 min/40°C (104°F) 50% d.c. ²⁾	-	220 A
10 min/40°C (104°F) 100% d.c. ²⁾	150 A	160 A
Open circuit voltage	89 V	89 V
Working voltage		
TIG	10,1 - 20,0 V	10,1 - 22,0 V
Electrode	20,4 - 30,0 V	20,4 - 32,0 V
Striking voltage (U _p)	10 kV	10 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	B	B
EMC emission class (in accordance with EN/IEC 60974-10)	A	A
Dimensions L x W x H (with handle)	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.
Weight	28,2 kg 62.17 lb.	30 kg 66.14 lb.
Mark of conformity	S, CE	S, CE

**MagicWave
4000 Comfort,
MagicWave
4000 Comfort MV**

	MW 4000 Comfort	MW 4000 Comfort MV
Mains voltage	3 x 400 V	3 x 200 - 240 V 3 x 380 - 460 V
Mains voltage tolerance	± 15 %	± 10 %
Mains frequency	50/60 Hz	50/60 Hz
Mains fuse protection (slow-blow)	35 A	63/35 A
Mains connection ¹⁾	Restrictions possible	Restrictions possible
Primary continuous power (100% d.c. ²⁾)	15.5 kVA	13.9 kVA
Cos phi	0,99	0,99
Welding current range		
TIG	3 - 400 A	3 - 400 A
Electrode	10 - 400 A	10 - 400 A
Welding current at		
10 min/40 °C (104 °F) 40% d.c. ²⁾	-	-
10 min/40 °C (104 °F) 45% d.c. ²⁾	400 A	400 A
10 min/40 °C (104 °F) 60% d.c. ²⁾	365 A	360 A
10 min/40 °C (104 °F) 100% d.c. ²⁾	310 A	300 A
Open circuit voltage	90 V	90 V
Working voltage		
TIG	10.1 - 26.0 V	10.1 - 26.0 V
Electrode	20.4 - 36.0 V	20.4 - 36.0 V
Striking voltage (U _p)	9.5 kV	9.5 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	F	F
EMC emission class (in accordance with EN/IEC 60974-10)	A	A
Dimensions L x W x H (with handle)	625 / 290 / 705 mm 24.6 / 11.4 / 27.8 in.	625 / 290 / 705 mm 24.6 / 11.4 / 27.8 in.
Weight	58.2 kg 128 lb.	60 kg 132.30 lb.
Mark of conformity	S, CE	S, CE, CSA

**MagicWave
5000 Comfort,
MagicWave
5000 Comfort MV**

	MW 5000 Comfort	MW 5000 Comfort MV
Mains voltage	3 x 400 V	3 x 200 - 240 V 3 x 380 - 460 V
Mains voltage tolerance	± 15%	± 10%
Grid frequency	50/60 Hz	50/60 Hz
Mains fuse protection (slow-blow)	35 A	63 / 35 A
Mains connection ¹⁾	Restrictions possible	Restrictions possible
Primary continuous power (100% D.C. ²⁾)	17.9 kVA	16.5 kVA
Cos phi	0.99	0.99

	MW 5000 Comfort	MW 5000 Comfort MV
Welding current range		
TIG	3 - 500 A	3 - 500 A
Electrode	10 - 440 A	10 - 440 A
Welding current at		
10 min/40 °C (104 °F) 40% D.C. ²⁾	500 A	500 A
10 min/40 °C (104 °F) 45% D.C. ²⁾	-	-
10 min/40 °C (104 °F) 60% D.C. ²⁾	440 A	440 A
10 min/40 °C (104 °F) 100% D.C. ²⁾	350 A	350 A
Open circuit voltage	90 V	90 V
Working voltage		
TIG	10.1 - 30.0 V	10.1 - 30.0 V
Electrode	20.4 - 37.6 V	20.4 - 37.6 V
Striking voltage (U _p)	9.5 kV	9.5 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	F	F
EMC device class (in accordance with EN/IEC 60974-10)	A	A
Dimensions L x W x H (with handle)	625/290/705 mm 24.6/11.4/27.8 in.	625/290/705 mm 24.6/11.4/27.8 in.
Weight	58.2 kg 128 lb.	60 kg 132.30 lb.
Mark of conformity	S, CE	S, CE, CSA

TransTig 2200 Comfort

	TT 2200 Comfort
Mains voltage	230 V
Mains voltage tolerance	-20 % / +15 %
Mains frequency	50 / 60 Hz
Mains fuse protection (slow-blow)	16 A
Mains connection ¹⁾	No restrictions
Primary continuous power (100% d.c. ²⁾)	3,0 kVA
Cos phi	0,99
Welding current range	
TIG	3 - 220 A
Electrode	10 - 180 A
Welding current at	
10 min/25°C (77°F) 50% ED ²⁾	220 A
10 min/25°C (77°F) 60% ED ²⁾	200 A
10 min/25°C (77°F) 100% ED ²⁾	170 A
10 min/40°C (104°F) 40% ED ²⁾	220 A
10 min/40°C (104°F) 60% ED ²⁾	180 A
10 min/40°C (104°F) 100% ED ²⁾	150 A

	TT 2200 Comfort
Open circuit voltage	84 V
Working voltage	
TIG	10,1 - 18,8 V
Electrode	20,4 - 27,2 V
Striking voltage (U _p)	9,5 kV
The arc striking voltage is suitable for manual operation.	
Degree of protection	IP 23
Type of cooling	AF
Insulation class	B
EMC emission class (in accordance with EN/IEC 60974-10)	A
Dimensions L x W x H (with handle)	485 / 180 / 390 mm 19.1 / 7.1 / 15.4 in.
Weight (without handle)	16,4 kg 37 lb.
Weight (with handle)	16,8 kg 37 lb.
Mark of conformity	S, CE

**TransTig
2500 / 3000 Com-
fort**

	TT 2500 Comfort	TT 3000 Comfort
Mains voltage	3 x 400 V	3 x 400 V
Mains voltage tolerance	± 15 %	± 15 %
Mains frequency	50/60 Hz	50/60 Hz
Mains fuse protection (slow-blow)	16 A	16 A
Mains connection ¹⁾	Z _{max} at PCC ³⁾ = 172 mOhm	Z _{max} at PCC ³⁾ = 97 mOhm
Primary continuous power (100% d.c. ²⁾)	5.1 kVA	5.7 kVA
Cos phi	0,99	0,99
Welding current range		
TIG	3 - 250 A	3 - 300 A
Electrode	10 - 250 A	10 - 300 A
Welding current at		
10 min/40 °C (104 °F) 45% d.c. ²⁾	-	300 A
10 min/40 °C (104 °F) 50% d.c. ²⁾	250 A	-
10 min/40 °C (104 °F) 60% d.c. ²⁾	240 A	270 A
10 min/40 °C (104 °F) 100% d.c. ²⁾	210 A	230 A
Open circuit voltage	85 V	85 V
Working voltage		
TIG	10.1 - 20.0 V	10.1 - 22.0 V
Electrode	20.4 - 30.0 V	20.1 - 32.0 V
Striking voltage (U _p)	10 kV	10 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF

	TT 2500 Comfort	TT 3000 Comfort
Insulation class	B	B
Dimensions L x W x H (with handle)	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.
Weight	24.2 kg 53.35 lb.	24.2 kg 53.35 lb.
Mark of conformity	S, CE	S, CE

TransTig 2500 / 3000 Com- fort MV

	TT 2500 Comfort MV	TT 3000 Comfort MV
Mains voltage	3 x 200 - 240 V 3 x 400 - 460 V 1 x 200 - 240 V	3 x 200 - 240 V 3 x 400 - 460 V 1 x 200 - 240 V
Mains voltage tolerance	± 10 %	± 10 %
Mains frequency	50 / 60 Hz	50 / 60 Hz
Mains fuse protection (slow-blow)		
3 x 400 - 460 V	16 A	16 A
3 x 200 - 240 V	32 A	32 A
1 x 200 - 240 V	32 A	32 A
Mains connection ¹⁾	Z _{max} at PCC ³⁾ = 172 mOhm	Z _{max} at PCC ³⁾ = 97 mOhm
Primary continuous power (100% d.c. ²⁾)		
3 x 400 - 460 V	4,7 kVA	5,9 kVA
3 x 200 - 240 V	4,1 kVA	5,0 kVA
1 x 200 - 240 V	4,3 kVA	4,3 kVA
Cos phi	0,99	0,99
Welding current range (3-phase)		
TIG	3 - 250 A	3 - 300 A
Electrode	10 - 250 A	10 - 300 A
Welding current range (single phase)		
TIG	3 - 220 A	3 - 220 A
Electrode	10 - 180 A	10 - 180 A
Welding current at 3 x 400 - 460 V		
10 min/40 °C (104 °F) 45% d.c. ²⁾	-	300 A
10 min/40 °C (104 °F) 50% d.c. ²⁾	250 A	-
10 min/40 °C (104 °F) 100% d.c. ²⁾	200 A	240 A
Welding current at 3 x 200 - 240 V		
10 min/40 °C (104 °F) 35% d.c. ²⁾	-	300 A
10 min/40 °C (104 °F) 40% d.c. ²⁾	250 A	-
10 min/40 °C (104 °F) 100% d.c. ²⁾	180 A	210 A
Welding current at 1 x 200 - 240 V		
10 min/40 °C (104 °F) 50% d.c. ²⁾	220 A	-
10 min/40 °C (104 °F) 55% d.c. ²⁾	-	220 A
10 min/40 °C (104 °F) 100% d.c. ²⁾	190 A	190 A
Open circuit voltage	85 V	85 V

	TT 2500 Comfort MV	TT 3000 Comfort MV
Working voltage		
TIG	10,1 - 20,0 V	10,1 - 22,0 V
Electrode	20,4 - 30,0 V	20,4 - 32,0 V
Striking voltage (U _p)	10 kV	10 kV
The arc striking voltage is suitable for manual operation		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	B	B
EMC emission class (in accordance with EN/IEC 60974-10)	A	A
Dimensions L x W x H (with handle)	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.	560 / 250 / 435 mm 22.0 / 9.8 / 17.1 in.
Weight	25,9 kg 57.10 lb.	25,9 kg 57.10 lb.
Mark of conformity	S, CE	S, CE

**TransTig
4000 Comfort,
TransTig
4000 Comfort MV**

	TT 4000 Comfort	TT 4000 Comfort MV
Mains voltage	3 x 400 V	3 x 200 - 240 V 3 x 380 - 460 V
Mains voltage tolerance	± 15 %	± 10 %
Mains frequency	50/60 Hz	50/60 Hz
Mains fuse protection (slow-blow)	35 A	63/35 A
Mains connection ¹⁾	Restrictions possible	Restrictions possible
Primary continuous power (100% d.c. ²⁾)	11.8 kVA	11.5 kVA
Cos phi	0,99	0,99
Welding current range		
TIG	3 - 400 A	3 - 400 A
Electrode	10 - 400 A	10 - 400 A
Welding current at		
10 min/40 °C (104 °F) 40% d.c. ²⁾	-	-
10 min/40 °C (104 °F) 45% d.c. ²⁾	400 A	400 A
10 min/40 °C (104 °F) 60% d.c. ²⁾	365 A	360 A
10 min/40 °C (104 °F) 100% d.c. ²⁾	310 A	300 A
Open circuit voltage	86 V	86 V
Working voltage		
TIG	10.1 - 26.0 V	10.1 - 26.0 V
Electrode	20.4 - 36.0 V	20.4 - 36.0 V
Striking voltage (U _p)	9.5 kV	9.5 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	F	F
EMC emission class (in accordance with EN/IEC 60974-10)	A	A

	TT 4000 Comfort	TT 4000 Comfort MV
Dimensions L x W x H (with handle)	625 / 290 / 475 mm 24.6 / 11.4 / 18.7 in.	625 / 290 / 475 mm 24.6 / 11.4 / 18.7 in.
Weight	39.8 kg 87.7 lb.	42.0 kg 92.6 lb.
Mark of conformity	S, CE	S, CE, CSA

**TransTig 5000
Comfort,
TransTig 5000
Comfort MV**

	TT 5000 Comfort	TT 5000 Comfort MV
Mains voltage	3 x 400 V	3 x 200 - 240 V 3 x 380 - 460 V
Mains voltage tolerance	± 15%	± 10%
Grid frequency	50/60 Hz	50/60 Hz
Mains fuse protection (slow-blow)	35 A	63 / 35 A
Mains connection ¹⁾	Restrictions possible	Restrictions possible
Primary continuous power (100% D.C. ²⁾)	15.1 kVA	14.2 kVA
Cos phi	0.99	0.99
Welding current range		
TIG	3 - 500 A	3 - 500 A
Electrode	10 - 500 A	10 - 500 A
Welding current at		
10 min/40 °C (104 °F) 40% D.C. ²⁾	500 A	500 A
10 min/40 °C (104 °F) 45% D.C. ²⁾	-	-
10 min/40 °C (104 °F) 60% D.C. ²⁾	450 A	440 A
10 min/40 °C (104 °F) 100% D.C. ²⁾	350 A	350 A
Open circuit voltage	86 V	86 V
Working voltage		
TIG	10.1 - 30.0 V	10.1 - 30.0 V
Electrode	20.4 - 40.0 V	20.4 - 40.0 V
Striking voltage (U _p)	9.5 kV	9.5 kV
The arc striking voltage is suitable for manual operation.		
Degree of protection	IP 23	IP 23
Type of cooling	AF	AF
Insulation class	F	F
EMC device class (in accordance with EN/IEC 60974-10)	A	A
Dimensions L x W x H (with handle)	625/290/475 mm 24.6/11.4/18.7 in.	625/290/475 mm 24.6/11.4/18.7 in.
Weight	39.8 kg 87.7 lb.	42.0 kg 92.6 lb.
Mark of conformity	S, CE	S, CE, CSA

Explanation of footnotes

- 1) connected to public mains supply with 230 / 400 V and 50 Hz
- 2) D.C. = Duty cycle
- 3) PCC = interface to the public grid
- 4) TIG welding
- 5) MMA welding
- 6) An emission class A device is not designed for use in residential areas supplied with power from a public low-voltage grid.
The electromagnetic compatibility can be influenced by conducted or radiated radio frequencies.

FRONIUS INTERNATIONAL GMBH

Froniusstraße 1, A-4643 Pettenbach, Austria

E-Mail: sales@fronius.com

www.fronius.com

Under www.fronius.com/contact you will find the addresses
of all Fronius Sales & Service Partners and locations



Find your
spareparts online



spareparts.fronius.com